



ATTENTION

After one rotation, press the button to stop immediately to prevent excessive cutting that may cause metal to shred.

FOLLOW US ON OUR SOCIALS

- kitchenmamaus
- kitchenmamaus
- KitchenMama
- support@shopkitchenmama.com

USER MAINTENANCE

- Use AA alkaline batteries only.
- Don't mix old and new batteries together. Do not mix alkaline, standard (carbon-zinc) and rechargeable (nickel-cadmium) batteries.
- Make sure the batteries are inserted in the correct polarity; if not, the opener won't operate or may cause battery leakage.
- Remove the batteries when not in use for extended periods of time. e Do not dispose of batteries in fire, they might explode. If disposing large quantities of batteries, contact your trash disposal company or municipal waste disposal department for instructions.
- Store in a dry place.
- Remove the batteries before wiping clean with a damp towel.
- Do NOT submerge in water, wash under running water, or wash in dishwasher.

TROUBLESHOOTING

The can opener is not working. What do I do?

Check the battery compartment. Make sure the batteries are in the right polarity and that the cover is securely in place.

Why is it rotating so slowly? It looks like it's struggling

The batteries might be drained already. Replace them and try again.

Why doesn't it detach from edge once it's done?

First, don't forcefully remove the can opener. Restart it by taking out the batteries. After reinserting the batteries