

# Code Patch



## Setting the UNIX/Linux Environment to Develop an AVR Application

By: Daniel Widyanto, ITB DSP Lab

### Features

- Setting GNU Toolchain
- Setting Debugger and Simulator

### Introduction

This application note will guide the UNIX/Linux user in building an AVR development environment.

### Setting GNU Toolchain

The GNU toolchain consists of GCC (GNU Collection Compiler), binutils, and library. These packages are usually installed in your Linux box, but usually it is configured only to build host architecture software.

To make it compile AVR binaries, one must download and reconfigure these toolchains.

### GCC-3.3.1

Only GCC above v.2.95 is available for AVR, except GCC-3.3.3, which is not work for AVR. GCC-3.3.1 is the only stable version of GCC when this application note was made. C++ is still in development in this version.

```

$ cd /temporary/working/directory
$ tar -xvzf gcc-core-3.3.1.tar.bz2
$ tar -xvzf gcc-g++-3.3.1.tar.bz2
OR
$ tar -xvzf gcc-3.3.1.tar.bz2
$ mkdir gcc-build
$ cd gcc-build
$ ../gcc-3.3.1/configure --target=avr \
  --prefix=/usr/local/atmel \
  --enable-language=c,c++ --disable-nls
$ make
$ make install (as root)

```

Package Name	Description	Download Location
<b>Binutils-2.14</b> binutils-2.14.tar.bz2	Binary utilities	<a href="http://freshmeat.net/projects/binutils/">http://freshmeat.net/projects/binutils/</a>
<b>GCC-3.3.1</b> gcc-3.3.1.tar.bz2 OR gcc-core-3.3.1.tar.bz2 gcc-g++-3.3.1.tar.bz2	C compiler	<a href="http://gcc.gnu.org/mirrors.html">http://gcc.gnu.org/mirrors.html</a>
<b>AVR-libc-1.0.4</b> avr-libc-1.0.4.tar.bz2	AVR C libraries	<a href="http://savannah.nongnu.org/download/avrlibc/">http://savannah.nongnu.org/download/avrlibc/</a>
<b>AVR libc - User Manual</b> avr-libc-user-manual-1.0.4.tar.bz2	AVR C libraries user manual	<a href="http://savannah.nongnu.org/download/avrlibc/">http://savannah.nongnu.org/download/avrlibc/</a>

Table 1. GNU Toolchain

The GNU Toolchain is a combination of GCC, binutils, and avr-libc versions. Not all of these combinations work. Please take a look at <http://winavr.sourceforge.net/package.html> for a working combination.

To start the installation, make a separate directory first. A separate directory makes it easy to remove.

```

$ su
$ mkdir /usr/local/atmel

```

### Binutils-2.14

Extract binutils, configure, and install using UNIX/Linux default installation. Option --prefix is used to arrange its output directory.

```

$ cd /temporary/working/directory
$ tar -xvzf binutils-2.14.tar.bz2
$ cd binutils-2.14
$ ./configure --target=avr --prefix=/usr/
  local/atmel \
  --disable-nls
$ make
$ make install (as root)

```

### AVR-libc-1.0.4

AVR libc has to be compiled within a new directory outside its source code directory. Otherwise, some of the AVR type library won't be compiled.

```

$ cd /temporary/working/directory
$ tar -xvzf avr-libc-1.0.4.tar.bz2
$ mkdir /temporary/working/directory/avr-libc
$ cd avr-libc
$ export PATH=/usr/local/atmel/bin:$PATH
$ ../avr-libc-1.0.4/configure --
  prefix=/usr/local/atmel
$ make
$ PATH=/usr/local/atmel/bin:$PATH
  make install (as root)

```

### AVR-libc-1.0.4 User Manual

AVR-libc usually come with built-in documentation. You need to install Doxygen to build these documents. This

package contains only AVR-libc documentation in HTML format, just in case you don't have Doxygen to build the AVR-libc documents. Extract it to any place that you like.

```
$ tar -xvzf avr-libc-user-manual-1.0.4.tar.bz2
-C /usr/local/atmel (as root)
```

### Setting Environment

After these toolchains are installed, you need to add the path in your environment shell. Assume you're using BASH, add this in your `.bash_profile` file

```
PATH=$PATH:/usr/local/avr/bin
export PATH
```

### Setting Debugger and Simulator

Debugger and simulator is useful to verify one's design. There are many free AVR debuggers and simulators around. This application note uses gdb and SimulAVR.

Package Name	Description	Download Location
<b>GDB-6.1</b> gdb-6.1.tar.gz	GNU Debugger	<a href="http://ftp.gnu.org/gnu/gdb">http://ftp.gnu.org/gnu/gdb</a> <a href="ftp://sources.redhat.com/pub/gdb/releases/">ftp://sources.redhat.com/pub/gdb/releases/</a>
<b>SimulAVR-0.1.2.1</b> simulavr-0.1.2.1.tar.bz2	AVR Simulator	<a href="http://savannah.nongnu.org/download/simulavr/">http://savannah.nongnu.org/download/simulavr/</a>

#### GDB-6.1 GDB

(GNU Debugger) is GNU's official debugger. GDB must be combined with SimulAVR to simulate AVR.

```
$ cd /temporary/working/directory
$ tar -xvzf gdb-6.1.tar.gz
$ cd gdb-6.1
$ ./configure --target=avr --
    prefix=/usr/local/atmel
$ make
$ make install (as root)
```

#### SimulAVR-0.1.2.1

SimulAVR provides an AVR emulator in your computer. The AVR registers and data as provided by SimulAVR. You can read these registers and data using GDB.

```
$ cd /working/directory
$ tar -xvzf simulavr-0.1.2.1.tar.bz2
$ cd simulavr-0.1.2.1
$ ./configure --prefix=/usr/local/atmel
$ make
$ PATH=/usr/local/atmel/bin:$PATH
    make install (as root)
```

## Code Patch

## Using STK500 Under UNIX/Linux Environment

By: **Daniel Widyanto, ITB DSP Lab**

### Introduction

This application note is a guide to use the STK500 features under a UNIX/Linux environment. To be able to use STK500 in Linux, one needs additional software. There are two software packages that can be used with STK500: AVRdude (formerly known as AVRprog) and UISP. It is recommended that you use UISP, since it can handle all of STK500 features.

### AVRdude-4.3.0

#### Installation

AVRdude can be downloaded from <http://savannah.nongnu.org/download/avrdude>. To install it, extract the source first.

```
$ tar -xvzf avrdude-4.3.0.tar.bz2
Then, configure, compile, and install.
$ cd avrdude-4.3.0
$ ./configure
$ make
$ su
$ make install
```

### Programming Devices on STK500

The typical command to use STK500 with avrdude is :

```
$ avrdude -c stk500 -p <device> \
-U <memory>:r|w|v:<filename>[:format]
[other_option]
```

Option explanation :

-c : Use to identify the programmer that is used.  
Currently, AVRdude supports STK200, STK500, avrisp, AVR910, butterfly.

-p : AVR device. Currently these AVR <device> are supported :

t15	AT Tiny15	1200	AT90S1200
2313	AT90S2313	2323	AT90S2323
2333	AT90S2333	2343	AT90S2343
4414	AT90S4414	4433	AT90S4433
4434	AT90S4434	8515	AT90S8515
8535	AT90S8535	m163	ATMEGA163
m169	ATMEGA169	m128	ATMEGA128
m103	ATMEGA103	m16	ATMEGA16
m8	ATMEGA8		

-U : Memory operation. Multiple -U can be used to operate on multiple memories at single command.

<memory> : memory type (flash or eeprom).

r | w | v : (r)ead memory to <filename>, (w)rite <filename> to memory, (v)erify memory against <filename>

[:format] : <filename> format. The option is:

```
i - Intel-hex format
s - Motorola S-record
r - Raw binary, little endian byte order
a - Auto
m - Immediate, the value is entered directly
```

#### Reading Flash/EEPROM

To read flash from a device on STK500, use the following command (assume you are using AT90S8515):

```
$ avrdude -c stk500 -p 8515 \
-U flash:r:8515_flash.hex:i
```

The AT90S8515 flash memory will be saved in

8515\_flash.hex. This file is in Intel-hex format. To read EEPROM, change flash to eeprom.

#### Writing Flash/EEPROM

To write flash to the device on STK500, use the following command (assume you are using AT90S8515):

```
$ avrdude -c stk500 -p 8515 \
-U flash:w:test.hex:i
```

AVRdude will automatically erase the device before it is programmed and verify the result. The test.hex file is in Intel-hex format. To write the EEPROM, change flash to eeprom.

#### Signature, Fuses, and LockBits

You must read the datasheet : fuse programming, lock-bit programming, and signature reading section to understand the magic number that is used to program the signature, fuses, and lockbits.

NOTE: Not all AVR devices support fuses/lockbits read/write in ISP programming mode.

Signature, fuses, and lockbits are located in special memory section (depend on AVR type). To see, where they are located, type (assume you are using ATmega16):

```
$ avrdude -c stk500 -p m16 -v
```

You will see something like this :  
(see table top of next page)

Memory Type	Paged	Page Size	Size	#Pages	MinW	MaxW	Polled	ReadBack
EEPROM	no	512	0	0	9000	9000	0xff	0xff
flash	yes	16384	128	128	4500	4500	0xff	0xff
lock	no	1	0	0	0	0	0x00	0x00
lfuse	no	1	0	0	0	0	0x00	0x00
hfuse	no	1	0	0	0	0	0x00	0x00
signature	no	3	0	0	0	0	0x00	0x00

It means that the signature is located in signature memory, fuse in lfuse and hfuse memory, and lock in lock memory. It may be different on different AVR devices. Usually, this name corresponds to the datasheet (eg. lfuse to describe *low-byte fuse* in ATmega16).

### Programming Fuses/LockBits

To program lockbits/fuses, use lock/lfuse/hfuse as memory type, replacing flash/EEPROM keyword in -U option. For example, to activate mode 2 BLB1 (Boot Lock Bit) in ATmega16, type (refer to AT Mega16 datasheet page 259)

```
$ avrdude -c stk500 -p m16 -U lock:w:0x2F:m
```

Notes: with m-modes, all values are located in filename section and are entered directly in the lockbit memory.

### UISP

UISP is far more advanced than AVRdude. UISP can be used to set advanced features in STK500 (setting STK500 oscillator, VTARGET, AREF). It also can be used to program STK500 in high-voltage mode.

### Installation

UISP can be downloaded from <http://savannah.nongnu.org/download/uisp/>. UISP only needs typical installation (extract, configure, compile, and install).

```
$ tar -xvf uisp-20040311.tar.bz2
$ cd uisp-20040311
$ ./configure
$ make
$ su
$ make install
```

### Programming STK500

Typical command to program STK500 is:

```
$ uisp -dserial=/dev/ttyS0 -dprog=stk500 \
-dpart=ATxxx --[upload|download|verify] \
--segment=flash|EEPROM|fuse \
if=<input_hex_file>
[of=<output_hex_file>]
```

Option explanation:

```
-dserial :location where your STK500 is attached. /
dev/ttyS0 for serial port 1, serial port 2 is /
dev/ttyS1, and so on
-dprog :selecting STK500 board
-dpart :device name. Use complete device name (eg,
-dpart=atmega16)
```

### Reading Flash/EEPROM

To read flash, use (assume you are using AT90S8515):

```
$ uisp -dserial=/dev/ttyS0 -dprog=stk500 \
-dpart=AT90S8515 --download --segment=
flash \ of=8515_flash.hex
```

The flash will be saved in 8515\_flash.hex. This is Motorola S-record format file. To read EEPROM, replace --segment=flash with --segment=EEPROM

### Writing Flash/EEPROM

To write flash, use (assume you are using AT90S8515):

```
$ uisp -dserial=/dev/ttyS0 -dprog=stk500 \
-dpart=AT90S8515 --upload --segment=flash \
if=test.hex
```

UISP can accept Intel 16-bit hex file or Motorola S-records (S1 and S2). The file type is automatically detected by UISP. It also erases the chip automatically.

### Programming Fuses/LockBits

Under UISP, fuses and lockbits programming is far more easy than AVRdude.

NOTE: Not all AVR device support fuses/lockbits read/write in ISP programming mode.

There are several additional option to program fuses and lockbits:

```
--rd_fuses : Read all fuses and print values
to screen / stdout
--wr_fuse_l=byte : Write fuse low byte
--wr_fuse_h=byte : Write fuse high byte
--wr_fuse_e=byte : Write fuse extended byte
--wr_lock=byte : Write lock bits. Argument is a
byte where each bit is:
Bit5 -> BLB12
Bit4 -> BLB11
Bit3 -> BLB02
Bit2 -> BLB01
Bit1 -> LB2
Bit0 -> LB1
```

Here's an example of how to program mode 2 BLB1 (Boot Lock Bit) in ATmega16 (refer to AT Mega16 datasheet page 259):

```
$ uisp -dserial=/dev/ttyS0 -dprog=stk500 \
-dpart=atmega16 --wr_lock=0x2F
```

### STK500 Additional Features

STK500 has many additional features, such as high-

voltage programming, on-board oscillator, VTARGET, AREF software controllable.

### High Voltage Programming

Refer to page 3-13 of the STK500 User Manual for high-voltage programming setup.

Add option -dhiv to uisp, eg:

```
$ uisp -dserial=/dev/ttyS0 -dprog=stk500 \
-dpart=AT90S8515 -dhiv --upload \
--segment=flash if=test.hex
```

### AREF setting

Refer to page 3-17 of the STK500 User Manual for AREF jumper setting.

### Reading AREF

Use option: --rd\_aref

NOTE: Due to a bug in the STK500 firmware, the read value is sometimes off by 0.1 from the actual value measured with a volt meter.

### Writing AREF

Use option: --wr\_aref=<value>

Valid values are 0.0 to 6.0 volts in 0.1 volt increments. Value can not be larger than the VTARGET value.

### VTARGET setting

Refer to page 3-16 of the STK500 User Manual for AREF jumper setting.

### Reading VTARGET

Use option: --rd\_vtg

NOTE: Due to a bug in the STK500 firmware, the read value is sometimes off by 0.1 from the actual value measured with a volt meter.

### Writing VTARGET

Use option: --wr\_vtg=<value>

Valid values are 0.0 to 6.0 volts in 0.1 volt increments. Value can not be smaller than the AREF value.

### Oscillator setting

Refer to page 3-20 STK500 User Manual for AREF jumper setting.

### Reading oscillator

Use option: --rd\_osc

The frequency is displayed in Hertz

### Writing oscillator

Use option: --wr\_osc=<value>

Set the oscillator frequency in Hertz, from 14.06 to 3686400.