

The MediaTek logo is an orange parallelogram with the word "MEDIATEK" in white, bold, sans-serif capital letters.

MEDIATEK

MT7933 RFB User Guide

Version: 1.3
Release date: 2022-10-20

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

Version History

Version	Date	Description
1.0	2020-11-27	Initial release
1.1	2021-10-01	Add photo and description of new version RFB
1.2	2021-10-27	Update GPIO table
1.3	2022-10-20	Update Figure 11

Table of Contents

Version History	2
Table of Contents	3
List of Figures	3
List of Tables	4
1 Introduction.....	5
1.1 General Description.....	5
2 Get Started with the HDK	6
2.1 Configuring the MT7933 HDK	6
2.2 Installing the FTDI Debug Board Drivers on Microsoft Windows	7
2.3 Downloading the Image Using the MT7933 HDK.....	9
3 Hardware Features	12
3.1 Features Description	12
3.1.1 Technology and Package	12
3.1.2 Power Management and Clock Source	12
3.1.3 Platform	12
3.1.4 Audio.....	12
3.1.5 Wi-Fi.....	12
3.1.6 Bluetooth	13
3.1.7 Miscellaneous	13
4 Hardware Feature Configuration.....	14
4.1 Microcontroller	14
4.2 Power Supply.....	14
4.3 Audio	16
4.4 Buttons	16
4.5 SD Card.....	17
4.6 Extension Connectors.....	18
4.7 RTC	29
4.8 FTDI Debug Board	29
5 Appendix	30
Exhibit 1 Terms and Conditions.....	31

List of Figures

Figure 1. Front view of MT7933 HDK and FTDI debug board	5
Figure 2. Jumpers and connectors on the MT7933 HDK	6
Figure 3. COM port associated with the MT7933 HDK	8
Figure 4. FlashBurningTool :FBTool_gui.exe	9
Figure 5. FlashBurningTool_User intrerface	10
Figure 6. FlashBurningTool_operation step 1	11
Figure 7. FlashBurningTool_operation step 2.....	11
Figure 8. Default power jumper plot.....	14
Figure 9. Power up the HDK using an AA or AAA batteries (J25)	15

Figure 10. SD card slot rework	17
Figure 11. GPIO pin-out extension connectors	18
Figure 12. FTDI debug board	29

List of Tables

Table 1. Jumper settings for system power input through USB connection	15
Table 2. Audio related function	16
Table 3. Buttons.....	16
Table 4. GPIO pin-out extension connectors	18
Table 5. GPIO pin multi-function definition.....	20

1 Introduction

1.1 General Description

MediaTek LinkIt™ for real-time operating system (RTOS) is a low-cost and easy-to-use Internet of Things (IoT) development platform to design, prototype, evaluate and implement IoT projects. The platform supports MT7933 hardware development kit (HDK). This user manual provides required knowledge on features of the HDK, including the pins, communication interfaces, core microcontroller unit (MCU) description, the networking capabilities and how to use them through the host driver.

MediaTek's MT7933 is a highly integrated single chip that features an Arm® Cortex-M33 application processor, a low power 1x1 802.11a/b/g/n/ax dual-band Wi-Fi subsystem, a Bluetooth v5.0 subsystem, an Audio subsystem with Cadence® Tensilica® HiFi4 processor and a Power Management Unit (PMU). The Wi-Fi subsystem and a Bluetooth v5.0 subsystem offer feature-rich wireless connectivity at high standards, and deliver reliable, cost-effective throughput from an extended distance. Optimized RF architecture and baseband algorithms provide superb performance and low power consumption. MT7933 is designed to support standard based features in the areas of security, quality of service and international regulations, giving end users the greatest performance any time and in any circumstance.

The MT7933 is based on Arm Cortex-M33 with floating point microcontroller (MCU) including SRAM/ROM memory. The chip also supports rich peripheral interfaces, including USB, UART, SDIO, I2C, SPI, I2S, and auxiliary ADC.

These features are used to download and debug a project on MT7933 HDK.

Figure 1 shows the front view of the HDK including a main board and an FTDI debug board.




Figure 1. Front view of MT7933 HDK and FTDI debug board

2 Get Started with the HDK

Before commencing the application development, you need to configure the development platform.

2.1 Configuring the MT7933 HDK

MT7933 HDK includes a main board (MT7933_BGA_RFB_V30) and an FTDI Debug board (MT733_FTDI_debug board_V10). Figure 2 shows the top view of the main board.




Figure 2. Jumpers and connectors on the MT7933 HDK

The description of pins (Figure 2) and their functionality is provided below.

1. **CON8** is a USB 5V power for MT7933 main board, or you can use external 5V power at **J1**.
2. **CON6** is a USB function com port which does not supply 5V power to main board.
3. Press **SW1** to reset the system. For more information about **SW2** to **SW4**, see Section 4.4.
4. For Wi-Fi and BT function, MT7933 main board reserves a **Wi-Fi SMA connector** and a **BT SMA connector**. Please connect external antenna to transmit and receive RF signals.

5. The FTDI debug board can transfer USB interface to UART interface. Using this debug board can debug through UART, transmit and receive a signal form PC.
6. U8 and U9 are on-board AMICs which can catch voice command.
7. U10 and U11 are audio speaker connectors which can connect 8-ohm/2W speaker to achieve voice assistant function.

The default configuration of the MT7933 HDK supports the following functionality:


1. Power supply. Attach a Micro-USB connector to the **CON8**.
2. Supports RTC interrupt.
3. Clock source — 32.768-kHz source crystal clock for the RTC mode or external clock operating on 32.768 kHz.
4. XTAL at 26 MHz.

2.2 Installing the FTDI Debug Board Drivers on Microsoft Windows

To configure the MT7933 HDK:

1. Ensure the FTDI debug board connects to MT7933 main board at **U14**.
2. Connect the FTDI debug board to the computer using a Micro-USB cable.
3. Connect a 5V power at MT7933_BGA_RFB CON8 with a Micro-USB cable.
4. Check whether your PC is running on X86 or X64 system. And download and install FTDI Windows serial port driver from [Here](#). (The red block shows in the following figure shows the file to download)

Currently Supported D2XX Drivers:

Operating System	Release Date	Processor Architecture					Comments
		x86 (32-bit)	x64 (64-bit)	ARM	MIPS	SH4	
Windows*	2017-08-30	2.12.28	2.12.28	-	-	-	WHQL Certified. Includes VCP and D2XX. Available as a setup executable. Please read the Release Notes and Installation Guides.
Windows RT	2014-07-04	1.0.2	-	1.0.2	-	-	A guide to support the driver (AN_271) is available here .
Linux	2018-06-22	1.4.8	1.4.8	1.4.8 ARMv5 soft-float 1.4.8 ARMv5 soft-float uClibc 1.4.8 ARMv6 hard-float *** 1.4.8 ARMv7 hard-float *** 1.4.8 ARMv8 hard-float ***	1.4.8 MIPS32 soft-float 1.4.8 MIPS32 hard-float 1.4.8 MIPS openwrt-uclibc		If unsure which ARM version to use, compare the output of <code>readelf</code> and <code>file</code> commands on a system binary with the content of <code>release/build/ftd2xx.txt</code> in each package. ReadMe  Video Install Guide

5. If your OS is Windows7 or 10, please open Windows **Control Panel** then click **System** and enter **Device Manager**.
6. In **Device Manager**, navigate to **Ports (COM & LPT)** (see Figure 3).
7. A new **COM** device should appear under **Ports (COM & LPT)** in **Device Manager**, as shown in Figure 3. Note the **COMx** port number of the serial communication port. This information is needed to send command and receive logs from the COM port.

The com port numbers (**COMx**) are different at different PC. In order to check the function of each com port, you can recognize the order of these com ports. As Figure 3 shows, the first com port (#1) means “DSP UART”, the second com port (#2) means “UART0”, the third com port (#3) means “UART1”, and the fourth com port (#4) means “CM33 UART”.




Figure 3. COM port associated with the MT7933 HDK

2.3 Downloading the Image Using the MT7933 HDK

The MT7933 HDK is embedded with 8MB flash memory. The boot options are either from the Flash memory or from the UART port.

To update the image on the MT7933 HDK:

1. Download the latest Image.
2. Ensure **U14** connects to an **FTDI debug board**.
3. Ensure **CON8** connects to 5V power with Micro-USB cable and **FTDI debug board** connects to PC with Micro-USB cable.
4. Check the **Device Manager** at PC. There are 4 USB serial ports as Figure 3 shows.
5. Decompress the image file and open the “FBTool_gui” tool. See the red box in Figure 4.

FlashBurningTool_V2.84 > FBTool_v2p84_win64_GUI >

名稱	修改日期	類型	大小
burn_files	2022/10/27 下午 07:46	檔案資料夾	
Include	2022/9/13 下午 01:25	檔案資料夾	
mtk_files	2022/10/5 下午 03:50	檔案資料夾	
png	2022/9/13 下午 01:25	檔案資料夾	
tcl	2022/9/13 下午 01:25	檔案資料夾	
tk	2022/9/13 下午 01:25	檔案資料夾	
_asyncio.pyd	2022/10/5 下午 07:23	Python Extension ...	63 KB
_bz2.pyd	2022/10/5 下午 07:23	Python Extension ...	85 KB
_ctypes.pyd	2022/10/5 下午 07:23	Python Extension ...	124 KB
_decimal.pyd	2022/10/5 下午 07:23	Python Extension ...	263 KB
_elementtree.pyd	2022/10/5 下午 07:23	Python Extension ...	174 KB
_hashlib.pyd	2022/10/5 下午 07:23	Python Extension ...	46 KB
_lzma.pyd	2022/10/5 下午 07:23	Python Extension ...	248 KB
_multiprocessing.pyd	2022/10/5 下午 07:23	Python Extension ...	29 KB
_overlapped.pyd	2022/10/5 下午 07:23	Python Extension ...	45 KB
_pytransform.dll	2022/10/5 下午 07:23	應用程式擴充	1,132 KB
_queue.pyd	2022/10/5 下午 07:23	Python Extension ...	28 KB
_socket.pyd	2022/10/5 下午 07:23	Python Extension ...	78 KB
_ssl.pyd	2022/10/5 下午 07:23	Python Extension ...	151 KB
_testcapi.pyd	2022/10/5 下午 07:23	Python Extension ...	111 KB
_tkinter.pyd	2022/10/5 下午 07:23	Python Extension ...	63 KB
base_library.zip	2022/10/5 下午 07:22	WinRAR ZIP archi...	769 KB
cli_cmds.txt	2022/8/16 下午 06:06	文字文件	1 KB
cli_his.txt	2022/10/28 上午 10:10	文字文件	1 KB
config.ini	2022/11/1 下午 02:27	組態設定	2 KB
debug_log.txt	2022/10/28 上午 10:10	文字文件	1 KB
FBTool_gui.exe	2022/10/5 下午 07:23	應用程式	2,495 KB
FBTool_gui.exe.manifest	2022/10/5 下午 07:23	MANIFEST 檔案	2 KB

Figure 4. FlashBurningTool :FBTool_gui.exe

6. Refer to Figure 5. Click “Open” button to navigate the folder of your scatter file (See the blue arrow in Figure 4). And press “Refresh” button.
7. Refer to Figure 5. Go to red box 1 and choose the file you want to burn into flash.
8. Refer to Figure 5. Go to red box 2 and choose the “COM33 UART” port of your PC (Please refer to Step 7 in Section 2.2 to check which USB serial port is CM33 UART port at your PC).
9. **Slide the rightmost side switch of “SW6” (pin6→7) and keep “SW1” pressed.** Refer to Figure 5. Click “Download” button (as red box 3 in Figure 5) and wait for FlashBurningTool feedback.
10. After clicking “Download” button then release “SW1” to start burning image. you can see “progress bar ” as Figure 6 and Figure 7 show.
11. You can check FlashBurningTool to see the progress bar of burning image.(See red box 4 in Figure 5 and wait to 100%)




Figure 5. FlashBurningTool_ User intrrface




Figure 6. FlashBurningTool_operation step 1



Figure 7. FlashBurningTool_operation step 2

3 Hardware Features

This chapter provides the main supported features of the MT7933 HDK. The detailed description of the features is provided in the upcoming sections.

3.1 Features Description

3.1.1 Technology and Package

- 10.6 mm x 10.6 mm BGA package

3.1.2 Power Management and Clock Source

- Integrates high efficiency power management unit with single 3.3V power supply input
- Supports 26-MHz crystal clock with low power operation in idle mode
- Supports 32-kHz crystal oscillator or internal 32-kHz for low power sleep mode

3.1.3 Platform

- Arm Cortex-M33 MCU with FPU with up to 300-MHz clock speed
- Embedded 1MB SRAM
- Supports external serial flash up to 16MB with eExecute In Place (XIP) and on-the-fly AES
- Supports hardware crypto engines including AES, DES/3DES, SHA, ECC, TRNG for network security
- Supports up to 47 General-Purpose IOs, which are multiplexed with SPI, I2C, Aux ADC, UART, and GPIO interfaces
- Supports 12 DMA channels

3.1.4 Audio

- Cadence Tensilica HiFi4 processor with 600-MHz clock speed
- Audio Codec with 2 ADC and 1 DAC channel
- Embedded 256KB SRAM memory
- Supports Voice Activity Detection (VAD) and keyword detection
- On-board headphone jack for external active speaker

3.1.5 Wi-Fi

- IEEE 802.11 1T1R a/b/g/n/ax 5GHz and 2.4GHz
- Supports 20 MHz, bandwidth in 2.4G/5GHz band, and MCS0 to MCS8
- Supports MU-MIMO RX
- Supports uplink MU-OFDMA TX and downlink MU-OFDMA RX

- Support STBC RX, LDPC TX, and RX Beamformee
- Wi-Fi security WPA/WPA2/WPA3 personal
- Supports 11ax TWT low power
- Integrated balun, PA, LNA, and T/R switch
- Supports antenna diversity

3.1.6 Bluetooth

- Bluetooth v5.0 with 2Mbps PHY rate, Long-range and LE Advertising Extensions
- Integrated balun and PA
- Supports Wi-Fi/Bluetooth coexistence

3.1.7 Miscellaneous

- Embedded eFuse to store specific device information and RF calibration data
- Advanced TDD mode Wi-Fi/Bluetooth coexistence scheme

4 Hardware Feature Configuration

4.1 Microcontroller

The MT7933 features an Arm Cortex-M33 processor, which is the most energy efficient Arm processor currently available. It supports the clock rates up to 200 MHz when core power is 0.7V and 300 MHz when core power is 0.8V. The MCU executes the Thump-2 instruction set for optimal performance and code size, including hardware division, single cycle multiplication and bit-field manipulation. The MT7933 includes a Memory Protection Unit (MPU) in Cortex-M33 MCU to detect unexpected memory access and provides other memory protection features. The MT7933 also includes FPU in Cortex-M33 MCU.

4.2 Power Supply

MT7933 HDK supports two types of power supply.

1. Power up with a Micro-USB connector.

An on-board switching regulator provides voltage of 3.3V for the MT7933 HDK based on MT7933F, if the power is supplied from an on-board Micro-USB connector **CON8** (Figure 2). This supply can be isolated from the switching regulator using the jumpers. Note that the jumpers **J2**, **J26**, **J3**, **J4**, **JP5** pin1 and pin2, **JP2** pin2 and pin3 and **JP3** pin2 and pin3 are required to be set on. More details on the jumpers can be found in Table 1.





Figure 8. Default power jumper plot

Table 1. Jumper settings for system power input through USB connection

Jumper	Usage	Comments
J1	External 5V power supply	Use external power source to supply 5V voltage to MT7933 BGA RFB. Pin 1 is 5V source. Pin2 is GND.
J2	DC-5V transfer to DC-3V3 current source	
J3	Current measurement (3V3)	Measure the current flow in the MT7933.
J4	3V3 for external LDO (1.8V and 0.8V)	
J5	3V3 for external components	
J25	AVDD33_VRTC battery power supply	Use AA or AAA battery for RTC 3V3 power. Pin1 is positive endpoint. Pin2 is GND.
J26	Current measurement in RTC mode	Measures the current flow in RTC mode for the MT7933.
JP2	Switch VCCIO to 3V3 power domain or 1V8 power domain	<p>Selecting pins 1 and 2, means VCCIO uses 3V3 power domain</p> <p>Selecting pins 2 and 3 means VCCIO uses 1V8 power domain</p> <p>Caution: The flash of MT7933_BGA_RFB by default uses 1V8 power domain. If you want to change VCCIO to 3V3 power domain, please rework flash to 3V3 power domain flash, for example W25Q128JVPIQ.</p>
JP3	Switch 1V8 VCCIO from internal PHYLDO or external LDO	<p>Selecting pins 1 and 2 means 1V8 VCCIO from internal PHYLDO</p> <p>Selecting pins 2 and 3 means 1V8 VCCIO from external Buck component</p>
JP5	Switch RTC 3V3 from DC-3V3 or AVDD33_VRTC	<p>Selecting pins 1 and 2 means VCCIO uses 3V3 power domain</p> <p>Selecting pins 2 and 3 means VCCIO uses 1V8 power domain</p>

2. Power up using an AA or AAA battery.

Connect an external AA or AAA battery to battery pin header (J25) to supply power to the system as Figure 9 shows. When using RTC mode, remove jumper J2 and plug in jumper J26. Jumper JP5 should be switched to pin2 and pin3. More details on the jumpers can be found in Table 1.

**Figure 9. Power up the HDK using an AA or AAA batteries (J25)**

4.3 Audio

The MT7933 HDK has onboard audio connector associated with different functionalities of the board (Figure 2). For detail of audio related function, refer to Table 2.

Table 2. Audio related function

item	Detail
J8	3.5-mm audio jack for external active speaker.
J10	Audio header for left speaker
J11	Audio header for right speaker
U8	AMIC for left channel (the microphone hole is set at back side of MT7933 BGA RFB)
U9	AMIC for right channel (the microphone hole is set at back side of MT7933 BGA RFB)
SW2	Audio volume up button
SW3	Audio volume down button

4.4 Buttons

The MT7933 HDK is equipped with buttons with the following functionality.

Figure 2 shows the push buttons. Table 3 lists the functions of the buttons.

Table 3. Buttons

Button	Name	Detail
SW1	SYSRST	Press SW1 to restart the MT7933 BGA RFB
SW2	Vol+	Audio volume up button
SW3	Vol-	Audio volume down button
SW4	RTC_EINT	Press SW4 to enable RTC mode
SW6	DIP switch	Slide the DIP switch to trigger strapping mode (download mode...)

4.5 SD Card

The MT7933 BGA RFB reserves an SD card slot which allows saving data into an SD card. Note that there are some registers placed at back side that need to be reworked before you use SD card. Refer to Figure 10 to switch between R748 and R749, R745 and R751, R746 and R747, R744 and R750, R754 and R755, R752 and R753 or R756 and R757.




Figure 10. SD card slot rework

4.6 Extension Connectors

The MT7933 HDK provides similar pin-out extension connectors for various sensor and device connectivity, as shown in Figure 11 and described in Table 5.

The board has 53 GPIOs multiplexed with other interfaces. Depending on the use case, you can configure each I/O functionality.




Figure 11. GPIO pin-out extension connectors

Table 4. GPIO pin-out extension connectors

Signal Name	Connector Pin Number	Signal Name	Connector Pin Number
GPIO_0	Reserved for flash	GPIO_27	CON2 - 2
GPIO_1	Reserved for flash	GPIO_28	CON2 - 3
GPIO_2	Reserved for flash	GPIO_29	Reserved for DSP UART
GPIO_3	Reserved for flash	GPIO_30	Reserved for DSP UART
GPIO_4	Reserved for flash	GPIO_31	Reserved for USB
GPIO_5	Reserved for flash	GPIO_32	Reserved for USB
GPIO_6	CON7 - 1	GPIO_33	Reserved for USB

Signal Name	Connector Pin Number	Signal Name	Connector Pin Number
GPIO_7	CON7 - 2	GPIO_34	Reserved for USB
GPIO_8	CON7 - 3	GPIO_35	J14 - 2
GPIO_9	CON7 - 4	GPIO_36	J14 - 1
GPIO_10	J21 - 1	GPIO_37	J14 - 4
GPIO_11	J22 - 1	GPIO_38	J14 - 3
GPIO_12	JP_131 - 1	GPIO_39	J14 - 6
GPIO_13	J22 - 3	GPIO_40	J14 - 5
GPIO_14	J22 - 5	GPIO_41	Reserved for I2C
GPIO_15	J22 - 7	GPIO_42	Reserved for UART1
GPIO_16	J21 - 7	GPIO_43	Reserved for I2C
GPIO_17	U13 - 1	GPIO_44	Reserved for UART1
GPIO_18	U13 - 3	GPIO_45	Reserved for I2C
GPIO_19	J21 - 5	GPIO_46	Reserved for I2C
GPIO_20	J21 - 3	GPIO_47	CON5 - 1
GPIO_21	U13 - 5	GPIO_48	Reserved for CM33 UART
GPIO_22	U13 - 7	GPIO_49	CON5 - 3
GPIO_23	U13 - 9	GPIO_50	Reserved for CM33 UART
GPIO_24	U13 - 11	GPIO_51	CON5 - 5
GPIO_25	Reserved for UART0	GPIO_52	CON5 - 6
GPIO_26	Reserved for UART0		

Table 5. GPIO pin multi-function definition

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
PAD_SYSRST_B	NA	PAD_SYSRST_B			PU	Chip hardware fundamental reset pin
SDIO_CLK	0000	GPIO[6]	I/O	I	PD	GPIO 6
	0001 *	SDIO_CLK	I			SDIO Clock
	0010	MSDC0_CLK	O			MSDC Clock
	0011	SPIM0_SCK	O			SPI0 (Master) Clock
	0100	CM33_GPIO_EINT0	I			CA33 EINT0
	0101	DEBUG_0	O			Debug signal
	0110	ANT_SELO	O			Antenna Select 0
	0111	BGF_EINT_10_B	I			
SDIO_CMD	0000	GPIO[7]	I/O	I	PU	GPIO 7
	0001 *	SDIO_CMD	I/O			SDIO Command
	0010	MSDC0_CMD	I/O			
	0011	SPIM0_CS_N	O			SPI0 (Master) Chip Select
	0100	CM33_GPIO_EINT1	I			CA33 EINT1
	0101	DEBUG_1	O			Debug signal
	0110	ANT_SEL1	O			Antenna Select 1
	0111	PINMUX_EXT_INT_N_IN	I			
SDIO_DAT0	0000	GPIO[8]	I/O	I	PU	GPIO 8
	0001 *	SDIO_DAT0	O			SDIO Data[0]
	0010	MSDC0_DAT0	I/O			MSDC0 data0
	0011	SPIM0_MISO	I			SPI0 (Master) Input
	0100	UART0_RTS	O			
	0101	DEBUG_2	O			Debug signal
	0110	ANT_SEL2	O			Antenna Select 2
	0111	CM33_GPIO_EINT0	I			CA33 EINT0
SDIO_DAT1	0000	GPIO[9]	I/O	I	PU	GPIO 9
	0001 *	SDIO_DAT1	I/O			SDIO Data[1]
	0010	MSDC0_DAT1	I/O			MSDC0 data1
	0011	SPIM0_MOSI	O			SPI0 (Master) Output
	0100	UART0_CTS	I			UART0 Control
	0101	DEBUG_3	O			Debug signal
	0110	ANT_SEL3	O			Antenna Select 3
	0111	CM33_GPIO_EINT1	I			CA33 EINT1
SDIO_DAT2	0000	GPIO[10]	I/O	I	PU	GPIO 10
	0001 *	SDIO_DAT2	I/O			SDIO Data[2]
	0010	MSDC0_DAT2	I/O			MSDC0 data2
	0011	I2SIN_DAT0	I			
	0100	UART0_RX	I			UART0 RX
	0101	DEBUG_4	O			Debug signal
	0110	I2C0_SCL	I/O			
	0111	CM33_GPIO_EINT2	I			CA33 EINT2
SDIO_DAT3	0000	GPIO[11]	I/O	I	PU	GPIO 11
	0001 *	SDIO_DAT3	I/O			SDIO Data[3]

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0010	MSDC0_DAT3	I/O			
	0011	I2SO_DAT0	O			I2SO Data
	0100	UART0_TX	O			UART0 TX
	0101	DEBUG_5	O			Debug signal
	0110	I2CO_SDA	I			I2CO Data
	0111	CM33_GPIO_EINT3	I			CA33 EINT3
GPIO_B_0	0000	GPIO[12]	I/O	O	PU	GPIO 12
	0001 *	CONN_BGF_UART0_TXD	O			
	0010	MSDC0_RST	O			MSDC0 reset
	0011	CONN_BT_TXD	O			
	0100	WIFI_TXD	O			
	0101	DEBUG_6	O			Debug signal
	0110	ANT_SEL3	O			Antenna Select 3
	0111	CM33_GPIO_EINT4	I			CA33 EINT4
GPIO_B_1	0000	GPIO[13]	I/O	I	PU	GPIO 13
	0001 *	USB_IDDIG	I			USB OTG ID pin
	0010	SPIM1_SCK	O			SPIM1 (Master) Clock
	0011	I2SO_BCK	O			I2SO BCK
	0100	UART1_RX	I			UART1 RX
	0101	DEBUG_7	O			
	0110	ANT_SEL4	O			Antenna Select 4
	0111	CM33_GPIO_EINT5	I			CA33 EINT5
GPIO_B_2	0000	GPIO[14]	I/O	O	PD	GPIO 14
	0001 *	USB_DRV_VBUS	O			USB OTG host mode driving enable output.
	0010	SPIM1_MOSI	O			SPI1 (Master) Output
	0011	I2SO_LRCK	O			I2SO LRCK
	0100					
	0101	DEBUG_8	O			Debug signal
	0110	ANT_SEL5	O			Antenna Select 5
	0111	CM33_GPIO_EINT6	I			CA33 EINT6
GPIO_B_3	0000	GPIO[15]	I/O	I	PD	GPIO 15
	0001 *	USB_OC	I			USB Host mode over-current input notify
	0010	SPIM1_MISO	I			SPI1 (Master) Input
	0011	I2SO_MCK	O			I2STX MCLK
	0100	I2SIN_MCK	O			I2SRX MCK
	0101	DEBUG_9	O			Debug signal
	0110	ANT_SEL6	O			Antenna Select 6
	0111	CM33_GPIO_EINT7	I			CA33 EINT7
GPIO_B_4	0000	GPIO[16]	I/O	I	PD	GPIO 16
	0001 *	USB_VBUS_VALID	I			USB device mode VBUS detect
	0010	SPIM1_CS_N	O			SPI1 (Master) Chip Select
	0011	IR_IN	I			
	0100	I2SIN_MCK	O			I2SRX MCLK

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0101	DEBUG_10	O			Debug signal
	0110	ANT_SEL7	O			Antenna Select 7
	0111	CM33_GPIO_EINT8	I			CA33 EINT8
GPIO_B_5	0000	GPIO[17]	I/O	I	PU	GPIO 17
	0001 *	CONN_BGF_UART0_RXD	I			
	0010	UART0_RX	I			UART0 RX
	0011	TDMIN_MCLK	I			
	0100	DMIC_CLK0	O			DMIC CLK0
	0101	DEBUG_11	O			Debug signal
	0110	ANT_SEL8	O			Antenna Select 8
	0111	CM33_GPIO_EINT9	I			CA33 EINT9
GPIO_B_6	0000	GPIO[18]	I/O	O	PU	GPIO 18
	0001 *	CONN_BT_TXD	O			
	0010	UART0_TX	O			UART0 TX
	0011	TDMIN_BCK	I			
	0100	DMIC_DAT0	I			DMIC DAT0
	0101	UART1_RX	I			UART1 Control
	0110	IR_IN	I			
	0111	CM33_GPIO_EINT10	I			CA33 EINT10
GPIO_B_7	0000	GPIO[19]	I/O	O	PD	GPIO 19
	0001 *	WIFI_TXD	O			
	0010	UART0_RTS	O			UART0 Control
	0011	I2C1_SDA	I			I2C1 Data
	0100	I2SIN_LRCK	O			I2SRX LRCK
	0101	UART1_TX	O			UART1 TX
	0110	PTA_EXT_IF_FREQ	I			
	0111	CM33_GPIO_EINT11	I			CA33 EINT11
GPIO_B_8	0000	GPIO[20]	I/O	I	PD	GPIO 20
	0001 *	CONN_WF_MCU_AICE_TCKC	I			
	0010	UART0_CTS	I			UART0 Control
	0011	I2C1_SCL	I			I2C1 clock
	0100	I2SIN_BCK	O			I2SRX BCK
	0101	DEBUG_12	O			Debug signal
	0110	PTA_EXT_IF_FACT	I			
	0111	CM33_GPIO_EINT12	I			CA33 EINT12
GPIO_B_9	0000	GPIO[21]	I/O	I	PU	GPIO 21
	0001 *	CONN_WF_MCU_AICE_TMSC	I/O			
	0010	PTA_EXT_IF_PRI	I/O			
	0011	TDMIN_LRCK	I/O			
	0100	DMIC_DAT1	I			DMIC DAT1
	0101	DEBUG_13	O			Debug signal
	0110	ANT_SEL9	O			Antenna Select 9
	0111	CM33_GPIO_EINT13	I			CA33 EINT13
GPIO_B_10	0000	GPIO[22]	I/O	I	PD	GPIO 22
	0001 *	CONN_BGF_MCU_AICE_TCKC	I			

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0010	PTA_EXT_IF_WLAN_ACT	O			
	0011	TDMIN_DI	I			
	0100	DMIC_DAT2	I			DMIC Data2
	0101	DEBUG_14	O			Debug signal
	0110	ANT_SEL10	O			Antenna Select 10
	0111	CM33_GPIO_EINT14	I			CA33 EINT14
GPIO_B_11	0000	GPIO[23]	I/O	I	PU	GPIO 23
	0001 *	CONN_BGF_MCU_AICE_TMISC	I/O			
	0010	DSP_URXD0	I			
	0011	I2C0_SDA	I/O			I2C0 Data
	0100	DMIC_DAT3	I			DMIC Data3
	0101	DEBUG_15	O			Debug signal
	0110	ANT_SEL11	O			Antenna Select 11
	0111	CM33_GPIO_EINT15				CA33 EINT15
GPIO_B_12	0000	GPIO[24]	I/O	O	PU	GPIO 24
	0001 *	ADSP_JTAG_TDO	O			DSP JTAG
	0010	DSP_UTXD0	O			
	0011	I2C0_SCL	I/O			I2C0 clock
	0100	DMIC_CLK1	O			DMIC CLK1
	0101	CM33_UART_TX	O			CM33 UART TX
	0110	ANT_SEL12	O			Antenna Select 12
	0111	CM33_GPIO_EINT16	I			CA33 EINT16
GPIO_B_13	0000	GPIO[25]	I/O	I	PD	GPIO 25
	0001 *	ADSP_JTAG_TCK	I			DSP JTAG
	0010	CM33_UART_RX	I			CM33 UART RX
	0011	UART0_RX	I			UART0 Control
	0100	SPIM0_SCK	O			SPIM0 clock
	0101					
	0110	UART1_RX	I			UART1 RX
	0111	CM33_GPIO_EINT17	I			CA33 EINT17
GPIO_B_14	0000	GPIO[26]		I	PU	GPIO 26
	0001 *	ADSP_JTAG_TRST	I			DSP JTAG
	0010	CM33_UART_TX	O			CM33 UART TX
	0011	UART0_TX	O			UART0 TX
	0100	SPIM0_CS_N	O			SPIM0 CS
	0101					
	0110	UART1_TX	O			UART1 TX
	0111	CM33_GPIO_EINT18	I			CA33 EINT18
GPIO_B_15	0000	GPIO[27]	I/O	I	PU	GPIO 27
	0001 *	ADSP_JTAG_TDI	I			DSP JTAG
	0010	CM33_UART_RTS	O			CM33 UART RTS
	0011	UART0_RTS	O			UART0 RTS
	0100	SPIM0_MISO	I			SPIM0 MISO
	0101					
	0110	UART1_RTS	O			UART1 Control

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0111	CM33_GPIO_EINT19	I			CA33 EINT19
GPIO_B_16	0000	GPIO[28]	I/O	I	PU	GPIO 28
	0001 *	ADSP_JTAG_TMS	I			DSP JTAG
	0010	CM33_UART_CTS	I			CM33 UART CTS
	0011	UART0_CTS	I			UART0 Control
	0100	SPIM0_MOSI	O			SPIM0 MOSI
	0101	SPIS_MISO	O			SPIS MISO
	0110	UART1_CTS	I			UART1 Control
	0111	CM33_GPIO_EINT20	I			CA33 EINT20
GPIO_R_0	0000	GPIO[29]	I/O	I	PU	GPIO29
	0001 *	DSP_URXD0	I			
	0010	ADSP_JTAG_TDO	O			DSP JTAG
	0011	PWM_0	O			PWM0
	0100	PTA_EXT_IF_PRI	I/O			
	0101	CONN_WF_MCU_TDO	O			
	0110	CM33_RSVD1	I			
	0111	CM33_GPIO_EINT21	I			CA33 EINT21
GPIO_R_1	0000	GPIO[30]	I/O	O	PD	GPIO 30
	0001 *	DSP_UTXD0	O			
	0010	ADSP_JTAG_TCK	I			DSP JTAG
	0011	PWM_1	O			PWM 1
	0100	PTA_EXT_IF_WLAN_ACT	O			
	0101	CONN_WF_MCU_TCK	I			
	0110	CM33_RSVD3	I/O			
	0111	CM33_GPIO_EINT22	I			CA33 EINT22
GPIO_R_2	0000	GPIO[31]	I/O	O	PD	GPIO 31
	0001 *	USB_DRV_VBUS	O			USB Host mode VBUS driving
	0010	ADSP_JTAG_TRST	I			DSP JTAG
	0011	PWM_2	O			PWM2
	0100	PTA_EXT_IF_FREQ	I			
	0101	CONN_WF_MCU_TDI	I			
	0110	CM33_RSVD0	I			
	0111	CM33_GPIO_EINT23	I			CA33 EINT23
GPIO_R_3	0000	GPIO[32]	I/O	I	PD	GPIO 32
	0001 *	USB_OC	I			USB Host mode over-current input notify
	0010	ADSP_JTAG_TDI	I			DSP JTAG
	0011	PWM_3	O			PWM3
	0100	PTA_EXT_IF_ACT	I			
	0101	CONN_WF_MCU_TRSR_B	I			
	0110	CM33_RSVD2	I			
	0111	CM33_GPIO_EINT24	I			CA33 EINT24
GPIO_R_4	0000	GPIO[33]	I/O	I	PD	GPIO 33
	0001 *	USB_VBUS_VALID	I			USB device mode VBUS detect
	0010	ADSP_JTAG_TMS	I			DSP JTAG

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0011	PWM_4	O			PWM 4
	0100	I2C1_SDA	I			I2C1 Data
	0101	CONN_WF_MCU_TMS	I			
	0110	CM33_RSVD4	O			
	0111	CM33_GPIO_EINT25	I			CA33 EINT25
GPIO_R_5	0000	GPIO[34]	I/O	I	PU	GPIO 34
	0001 *	USB_IDDIG	I			USB OTG ID pin
	0010	I2C0_SCL	I			I2C0 clock
	0011	PWM_5	O			PWM 5
	0100	I2C1_SCL	I			I2C1 clock
	0101	EXT_CK	I			
	0110	DEBUG_0	O			Debug signal
	0111	CM33_GPIO_EINT26	I			CA33 EINT26
GPIO_R_6	0000	GPIO[35]	I/O	O	PD	GPIO 35
	0001 *	UART0_TX	O			UART0 TX
	0010	CM33_UART_RTS	O			CM33 UART RTS
	0011	PWM_6	O			PWM 6
	0100	PWM_2	O			PWM 2
	0101	CONN_BGF_MCU_TDO	O			
	0110	DEBUG_1	O			Debug signal
	0111	CM33_GPIO_EINT27	I			CA33 EINT27
GPIO_R_7	0000 *	GPIO[36]	I/O	I	PD	GPIO 36
	0001	DBSYS_NTRST	I			
	0010	CM33_UART_CTS	I			CM33 UART CTS
	0011	PWM_7	O			PWM 7
	0100	PWM_3	O			PWM 3
	0101	CONN_BGF_MCU_TCK	I			
	0110	DEBUG_2	O			Debug signal
	0111	CM33_GPIO_EINT28	I			CA33 EINT28
GPIO_R_8	0000 *	GPIO[37]	I/O	I	PD	GPIO 37
	0001	DBSYS_SWCLK_TCLK	I			
	0010	I2C1_SDA	I			I2C1
	0011	PWM_8	O			PWM 8
	0100	I2C0_SDA				I2C 0
	0101	CONN_BGF_MCU_TDI	I			
	0110	DEBUG_3	O			Debug signal
	0111	CM33_GPIO_EINT29	I			CA33 EINT29
GPIO_R_9	0000 *	GPIO[38]	I/O	I	PD	GPIO 38
	0001	DBSYS_TDI	I			
	0010	CM33_UART_TX	O			CM33 UART TX
	0011	PWM_9	O			PWM 9
	0100	I2C0_SDA	I/O			I2C0 Data
	0101	CONN_BGF_MCU_TRST_B	I			
	0110	I2C1_SCL	I/O			I2C1
	0111	CM33_GPIO_EINT30	I			CA33 EINT30

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
GPIO_R_10	0000 *	GPIO[39]	I/O	I	PD	GPIO 39
	0001	DBSYS_SWDIO_TMS	I/O			
	0010	I2C0_SDA	I			I2C0 Data
	0011	PWM_10	O			PWM 10
	0100	DSP_URXD0	I			
	0101	CONN_BGF_MCU_TMS	I			
	0110	ANT_SELO	O			Antenna Select 0
	0111	BGF_EINT_10_B	I			
GPIO_R_11	0000 *	GPIO[40]	I/O	O	PU	GPIO 40
	0001	DBSYS_TDO	O			
	0010	CM33_UART_RX	I			
	0011	PWM_11	O			PWM 11
	0100	DSP_UTXD0	O			
	0101	UART0_RX	I			UART0 RX
	0110	ANT_SEL1	O			Antenna Select 1
	0111	PINMUX_EXT_INT_N_IN	I			
GPIO_T_0	0000	GPIO[41]	I/O	I	PD	GPIO 41
	0001	CM33_RSVD0	I			
	0010 *	DBSYS_NTRST	I			CM33 JTAG
	0011	I2C0_SDA	I			I2C0 Data
	0100	CONN_BGF_UART0_RXD	I			
	0101	I2C1_SDA	1			I2C1 Data
	0110	ANT_SEL2	O			Antenna Select 2
	0111	CM33_GPIO_EINT0	I			CA33 EINT0
GPIO_T_1	0000	GPIO[42]	I/O	I	PD	GPIO 42
	0001	CM33_RSVD1	I			
	0010 *	DBSYS_SWCLK_TCLK	I			CM33 JTAG, CM33_SWD
	0011	UART1_RX	I			UART1 RX
	0100	UART0_RX	I			UART0 RX
	0101	DSP_URXD0	I			
	0110	ANT_SEL3	O			Antenna Select 3
	0111	CM33_GPIO_EINT1	I			CA33 EINT1
GPIO_T_2	0000	GPIO[43]	I/O	I	PD	GPIO 43
	0001	CM33_RSVD2	I			
	0010 *	DBSYS_TDI	I			CM33 JTAG
	0011	I2C0_SCL	I			I2C0 clock
	0100	CONN_BGF_UART0_TXD	O			
	0101	I2C1_SCL	1			I2C1 clock
	0110	ANT_SEL4	O			Antenna Select 4
	0111	CM33_GPIO_EINT17	I			CA33 EINT17
GPIO_T_3	0000	GPIO[44]	I/O	I	PD	GPIO 44
	0001	CM33_RSDV3	I/O			
	0010 *	DBSYS_SWDIO_TMS	I			CM33 JTAG, CM33_SWD
	0011	UART1_TX	O			UART1 TX
	0100	UART0_TX	O			UART0 TX

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0101	DSP_UTXD0	O			
	0110	ANT_SEL5	O			Antenna Select 5
	0111	CM33_GPIO_EINT18	I			CA33 EINT18
GPIO_T_4	0000	GPIO[45]	I/O	O	PU	GPIO 45
	0001	CM33_RSVD4	O			
	0010 *	DBSYS_TDOO	O			CM33 JTAG
	0011	I2C1_SDA	I			I2C1 Data
	0100	WIFI_TXD	O			
	0101	PWM_0	O			PWM0
	0110	ANT_SEL6	O			Antenna Select 6
	0111	CM33_GPIO_EINT19	I			CA33 EINT19
GPIO_T_5	0000	GPIO[46]	I/O	O	PU	GPIO 46
	0001 *	SPIM0_SCK	O			SPIM0 SCK
	0010	CM33_TRACE_CLK	O			
	0011	I2C1_SCL	I			I2C1
	0100	ONN_WF_MCU_AICE_TCKC	I			
	0101	PWM_1	O			PWM 1
	0110	ANT_SEL7	O			Antenna Select 7
	0111					
KPROW_0	0000	GPIO[47]	I/O	O	PU	GPIO 47
	0001 *	SPIM0_CS_N	O			SPIM0 CS
	0010	CM33_TRACE_D3	O			
	0011	KEYPAD_KPROW_0	I/O			
	0100	CONN_WF_MCU_AICE_TMSC	I/O			
	0101	PWM_2	O			PWM 2
	0110	ANT_SEL8	O			Antenna Select 8
	0111	CM33_GPIO_EINT2	I			CA33 EINT2
KPROW_1	0000	GPIO[48]	I/O	I	PU	GPIO 48
	0001 *	CM33_UART_RX	I			
	0010	CM33_TRACE_D2	O			
	0011	KEYPAD_KPROW_1	I/O			
	0100	DSP_URXD0	I			
	0101	PWM_3	O			PWM 3
	0110	ANT_SEL9	O			Antenna Select 9
	0111	AUDIO_DEBUG_IN_0	I			
KPROW_2	0000	GPIO[49]	I/O	O	PU	GPIO 49
	0001 *	CM33_UART_TX	O			
	0010	CM33_TRACE_D1	O			
	0011	KEYPAD_KPROW_2	I/O			
	0100	CONN_BT_TXD	O			
	0101	PWM_4	O			PWM 4
	0110	ANT_SEL10	O			Antenna Select 10
	0111	AUDIO_DEBUG_IN_1	I			
KPCOL_0	0000	GPIO[50]	I/O	O	PU	GPIO 50
	0001 *	CM33_UART_TX	O			

IO Name	CR Value Default*	Name	Dir	Default		Description
				Dir	PU/PD	
	0010	CM33_TRACE_D0	O			
	0011	KEYPAD_KPCOL_0	I			
	0100	DSP_UTXD0	O			
	0101	PWM_5	O			PWM 5
	0110	ANT_SEL11	O			Antenna Select 11
	0111	AUDIO_DEBUG_IN_2	I			
KPCOL_1	0000	GPIO[51]	I/O	I	PD	GPIO 51
	0001 *	SPIM0_MISO	I			SPIM0 MISO
	0010	CM33_SWO	O			
	0011	KEYPAD_KPCOL_1	I			
	0100	CONN_BGF_MCU_AICE_TCKC	I			
	0101	PWM_6	O			PWM 6
	0110	ANT_SEL12	O			Antenna Select 12
	0111	AUDIO_DEBUG_IN_3	I			
KPCOL_2	0000	GPIO[52]	I/O	O	PU	GPIO 52
	0001 *	SPIM0_MOSI	O			SPIM0 MOSI
	0010	CM33_UART_RX	I			CM33 UART RX
	0011	KEYPAD_KPCOL_2	I			
	0100	CONN_BGF_MCU_AICE_TCKC	I/O			
	0101	PWM_7	O			PWM 7
	0110	UART1_TX	O			UART1 TX
	0111	AUDIO_DEBUG_IN_4	I			

4.7 RTC

The MT7933 HDK features an RTC module. The clock source operates at 32.768-kHz crystal oscillator or an external clock source. The RTC has a built-in accurate timer to wake up the system when the user-defined timer expires. The RTC uses a different power source from the Power Management Unit (PMU). In retention mode, the PMU is turned off while the RTC module remains powered on. The RTC module only consumes 3μA in retention mode. The RTC has a dedicated PMU control pin, RTC_PMU_EN (pin F12), used to turn the power on when the RTC timer expires and turn the power off to enter the hibernate mode.

4.8 FTDI Debug Board

By default, MT7933 BGA RFB should connect to an FTDI debug board at U14 (Figure 2). This FTDI debug board (Figure 12) allows UART signal being converted to USB signal. This debug board also provides a Micro-USB connector to connect with your PC with USB cable.




Figure 12. FTDI debug board

5 Appendix



Board name	Schematic
MT7933_BGA_RFB_V22	 IOT_MT7933_BGA _RFB_4L_V22_MTK
MT7933_FTDI_Debug Board_V11	 IOT_MT7933_FTDI _debug_board_4L

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.