

Lesson 5 Control Multiple PWM Servos

1. Working Principle

PWM servo can be controlled by sending pulse signal so that you can change servo port, rotation angle and rotation time in program to control servo.

The path to the source code of the program is 5.Hardware Basic Learning/Python Development/Program Files/Control Multiple PWM Servos /main.py

```

1  import time
2  from PWMServo import PWMServo
3
4  # Control multiple PWM servos
5
6  pwm = PWMServo()
7  pwm.work_with_time()
8
9  if __name__ == '__main__':
10     pwm.run(1, 500, 1000) #ID1 PWM servo is set as 500 pulse width. The running time is 1000ms (PWM
11                             servo cannot read the current position, so the running time can not be controlled at the first time)
12     pwm.run(2, 500, 1000) # The ID2 PWM servo is set as 500 width pulse and the running time is set as
13                             1000ms.
14     time.sleep_ms(2000) # The delay of 2000ms
15
16     pwm.run(1, 2500, 2000) # The ID1 PWM servo is set as 2500 width pulse and the running time is set
17                             as 2000ms.
18     pwm.run(2, 2500, 2000) # The ID2 PWM servo is set as 500 width pulse and the running time is set as
19                             2000ms.
20     time.sleep_ms(2000) # The delay of 2000ms

```

PWM servo mainly calls run() function in PWMServo library. Take the code “pwm.run(1, 500, 1000)” as example.



The first parameter “1” is the port number of PWM servo. Here is No.1 port.

The second parameter “500” is the rotation position which is converted by pulse width data (pulse width= $11.1 \times \text{angle} + 500$, the formula just for your information). Therefore, the parameter 500 corresponds to 0° rotation angle.

The third parameter “1000” is the rotation time (unit: ms). The parameter here is 1000, i.e, 1000ms.

2. Preparation


Connect two PWM servos to PWM servo ports on MaxArm controller. Take connecting two LFD-01 servos (5V servo) to No.1 and No.2 ports as example. The wiring method is as follow:




Note: Please note the direction of servo cable, otherwise servo may burn out (S pin is signal terminal).

3. Operation Steps


- 1) Please connect MaxArm to Python editor according to the tutorial in folder "4. Underlying Program Learning/Python Development/Lesson 1 Set Development Environment".



- 2) After connecting, change the path of Workspace to “5.Hardware Basic Learning/Python Development” and select “Program Files”.



- 3) Double click folder “Control Multiple PWM Servos”, and then double click “main.py” to open program.



4) Click on the download icon to download program to ESP32 controller.




5) When the terminal prints the prompt, as shown in the image below, it means download completed.



6) After downloading, click on the reset icon or press the reset button on ESP32 controller to run program.






4. Project Outcome

When running program, two LFD-01M servos will rotate from 0° to 180° , and then to 0° . After the servos stop rotating, exit program automatically.


5. Function Extension


The rotation position set in program is from 0° to 180° , and then to 0° . You can modify the rotation position by modifying the corresponding code. Here the second parameter of run() function of No.1 servo is changed from 500 to 2500, and the second parameter of the run() function of No.2 servo is changed from 2500 to 500. The specific operation steps are as follow:

Find the following program code:




- 1) Change the second parameter of run() function of No.1 servo from 500 to 2500, and the second parameter of the run() function of No.2 servo from 2500 to 500, as shown in the image below:



- 2) After modifying, click on  icon to check grammar. In the mean time, the terminal will show the following prompt.



- 3) Click on  icon and refer to “Operation Steps 4-6” to download and run the program.