

Wiring Pi

GPIO Interface library for the Raspberry Pi



Reference

Before using the **WiringPi** GPIO library, you need to include its header file in your programs:

```
#include <wiringPi.h>
```

You may also need to add

```
-I/usr/local/include -L/usr/local/lib -lwiringPi
```

to the compile line of your program depending on the environment you are using. The important one is **-lwiringPi**

You may also need additional **#include** lines, depending on the modules you are using.

Reference/API Pages

- [WiringPi Setup functions](#)
- [Core wiringPi functions](#)

These two above are the most important features of **wiringPi**. Below are additional functions and libraries that comprise the main **wiringPi** release.

- [Raspberry Pi specific functions](#)
- [Timing functions](#)
- [Program priority, timing and threads](#)
- [Serial library](#)
- [SPI library](#)
- [I2C library](#)
- [Shift library](#)
- [Software PWM library](#)
- [Software tone library](#)

