


# YAW RATE SENSOR COMMUNICATION STOP MODE

## CIRCUIT DESCRIPTION


DTC No.	DTC Detecting Condition	Trouble Area
U0123/62	<ul style="list-style-type: none"> <li>Skid control ECU terminal IG1 voltage is 10 V or more, and data is not received from the yaw rate sensor for more than 1 sec.</li> <li>Skid control ECU terminal IG1 voltage is 10 V or more, and data cannot be received from the yaw rate sensor more than once within 5 sec. This situation repeatedly occurs more than 10 times.</li> </ul>	<ul style="list-style-type: none"> <li>Yaw rate sensor (internal malfunction)</li> <li>Power source circuit of yaw rate sensor</li> </ul>
U0124/95	<ul style="list-style-type: none"> <li>Skid control ECU terminal IG1 voltage is 10 V or more, and data is not received from the deceleration sensor for more than 1 sec.</li> <li>Skid control ECU terminal IG1 voltage is 10 V or more, and data cannot be received from the deceleration sensor more than once within 5 sec. This situation repeatedly occurs more than 10 times.</li> </ul>	<ul style="list-style-type: none"> <li>Yaw rate sensor (internal malfunction)</li> <li>Power source circuit of yaw rate sensor</li> </ul>

## WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK WIRE HARNESS(IG, GND)



- (a) Disconnect the connector (Y1) from the yaw rate sensor.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified value
Y1-1 (GND) – Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified value
Y1-5 (IG) – Body ground	IG switch ON	10 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE YAW RATE SENSOR (SEE PAGE 32-71)