

DTC	B1653/35	SEAT POSITION SENSOR ASSEMBLY MALFUNCTION
------------	-----------------	--


CIRCUIT DESCRIPTION

The seat position airbag sensor circuit consists of the airbag sensor assy center and the seat position airbag sensor.

DTC B1653/35 is recorded when a malfunction is detected in the seat position airbag sensor circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1653/35	<ul style="list-style-type: none"> The airbag sensor assy center receives a line short circuit signal, an open circuit signal, a short circuit to ground signal or a short circuit to B+ signal in the seat position airbag sensor circuit for 2 seconds. Seat position airbag sensor malfunction Airbag sensor assy center malfunction 	<ul style="list-style-type: none"> Seat position airbag sensor Airbag sensor assy center Floor wire

WIRING DIAGRAM




INSPECTION PROCEDURE

CAUTION:

Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the airbag sensor assy center.
- (d) Disconnect the connectors from the horn button assy.
- (e) Disconnect the connectors from the front passenger airbag assy.
- (f) w/ Side airbag:
Disconnect the connector from the front seat airbag assy LH.
- (g) w/ Side airbag:
Disconnect the connector from the front seat airbag assy RH.
- (h) w/ Curtain shield airbag:
Disconnect the connector from the curtain shield airbag assy LH.
- (i) w/ Curtain shield airbag:
Disconnect the connector from the curtain shield airbag assy RH.
- (j) Disconnect the connector from the front seat outer belt assy LH.
- (k) Disconnect the connector from the front seat outer belt assy RH.

1 CHECK DTC



- (a) Connect the connectors to the airbag sensor assy center.
- (b) Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (d) Clear the DTCs stored in memory (see page 05-1464).
- (e) Turn the ignition switch to the LOCK position.
- (f) Turn the ignition switch to the ON position and wait for at least 60 seconds.
- (g) Check the DTCs (see page 05-1464).

OK:

DTC B1653/35 is not output.

HINT:

Codes other than code B1653/35 may be output at this time, but they are not related to this check.

NG

Go to step 2

OK

USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)

2 CHECK CONNECTION OF CONNECTORS

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Check that the connectors are properly connected to the airbag sensor assy center and the seat position airbag sensor.

OK:


The connectors are connected.

NG

CONNECT CONNECTORS, THEN GO TO STEP 1

OK

3 CHECK FLOOR WIRE (OPEN)



- Disconnect the connectors from the airbag sensor assy center and the seat position airbag sensor.
- TMC Made:
Using a service wire, connect B11-2 and B11-4 of connector "C".
- TMMK Made:
Using a service wire, connect B11-2 and B11-5 of connector "C".

NOTICE:

Do not forcibly insert a service wire into the terminals of the connector when connecting.

- Measure the resistance according to the value(s) in the table below.


Standard:

Tester connection	Condition	Specified condition
A22-9 (DSP+) – A22-17 (DSP-)	Always	Below 1 Ω

NG

REPAIR OR REPLACE FLOOR WIRE


OK

4 CHECK FLOOR WIRE (SHORT)

- Disconnect the service wire from connector "C".
- Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A22-9 (DSP+) – A22-17 (DSP-)	Always	1 MΩ or Higher


NG**REPAIR OR REPLACE FLOOR WIRE****OK****5 CHECK FLOOR WIRE (TO B+)**

- Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A22-9 (DSP+) – Body ground	Ignition switch ON	Below 1 V
A22-17 (DSP-) – Body ground	Ignition switch ON	Below 1 V


NG**REPAIR OR REPLACE FLOOR WIRE****OK**

6 CHECK FLOOR WIRE (TO GROUND)

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A22-9 (DSP+) – Body ground	Always	1 MΩ or Higher
A22-17 (DSP-) – Body ground	Always	1 MΩ or Higher

NG**REPAIR OR REPLACE FLOOR WIRE****OK****7 CHECK SEAT POSITION AIR BAG SENSOR**

- Connect the connectors to the airbag sensor assy center.
- Connect the connector to the seat position airbag sensor.
- Connect the negative (–) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-1464).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (see page 05-1464).

OK:**DTC B1653/35 is not output.****HINT:**

Codes other than code B1653/35 may be output at this time, but they are not related to this check.

NG**Go to step 8****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-1456)**

8 REPLACE SEAT POSITION AIR BAG SENSOR


- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Replace the seat position airbag sensor (see page 60-69).

HINT:

Perform the inspection using parts from a normal vehicle if possible.

NEXT

9 CHECK AIR BAG SENSOR ASSY CENTER



- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-1464).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (see page 05-1464).

OK:

DTC B1653/35 is not output.

HINT:

Codes other than code B1653/35 may be output at this time, but they are not related to this check.

NG

**REPLACE AIR BAG SENSOR ASSY CENTER
(SEE PAGE 60-59)**

OK

END