

Service Hints

B1 Back-Up Light SW (M/T)

1-2 : Closed with the shift lever at R position

A4 Back-Up Light SW (A/T)

3-2 : Closed with the shift lever at R position

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A4	36 (LHD 1MZ-FE)	B1	38 (*1)	R14	43 (LHD)
	38 (*1)		48 (*2)		53 (RHD)
	46 (RHD 1MZ-FE)	R13	43 (LHD)		
	48 (*2)		53 (RHD)		

* 1 : LHD 2AZ-FE, 1AZ-FE

* 2 : RHD 2AZ-FE, 1AZ-FE

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2R	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK1	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	74 (RHD)	

▽ : Ground Points

Code	See Page	Ground Points Location
BS	64 (LHD)	Lower Back Panel Center
	76 (RHD)	

○ : Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B7	64 (LHD)	Floor Wire	B7	76 (RHD)	Floor Wire