


HEATER RELAY CIRCUIT

CIRCUIT DESCRIPTION

The heater relay is switched on by signals from the A/C amplifier. It supplies power to the blower motor.

WIRING DIAGRAM



INSPECTION PROCEDURE


1 CHECK FUSE(HTR)

- (a) Remove the HTR fuse from the engine room J/B and driver side J/B.
- (b) Check that the continuity exists of HTR fuse.

NG REPLACE FUSE

OK

2 INSPECT HEATER BLOWER MOTOR RELAY ASSY



- (a) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connected	Condition	Specified condition
3-5	Always	10 kΩ or higher
3-5	When battery voltage applied to terminals 1 and 2	Below 1.0 Ω
3-4	Always	Below 1.0 Ω
3-4	When battery voltage applied to terminals 1 and 2	10 kΩ or higher

NG REPLACE HEATER BLOWER MOTOR RELAY ASSY

OK

3 CHECK HARNESS AND CONNECTOR(HEATER CONTROL HOUSING SUB-ASSY – BATTERY)

1MZ-FE: A/C Control Assembly Connector Wire Harness View:



- (a) Remove the A/C amplifier with assy connectors still connected.

- (b) 1MZ-FE:

Measure voltage according to the value(s) in the table below.

Standard:

Tester connected	Condition	Specified condition
A13-32 (HR) – Body ground	Ignition switch OFF	0 V
A13-32 (HR) – Body ground	Ignition switch ON (Blower switch ON)	Below 1.0 V
A13-32 (HR) – Body ground	Ignition switch ON (Blower switch OFF)	10 to 14 V

- (c) 2AZ-FE:

Measure voltage according to the value(s) in the table below.

Standard:

Tester connected	Condition	Specified condition
A40-15 (HR) – Body ground	Ignition switch OFF	0 V
A40-15 (HR) – Body ground	Ignition switch ON (Blower switch ON)	Below 1.0 V
A40-15 (HR) – Body ground	Ignition switch ON (Blower switch OFF)	10 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK HARNESS AND CONNECTOR(BLOWER W/FAN MOTOR, BLOWER MOTOR CONTROL – BATTERY)

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE