


## ECM POWER SOURCE CIRCUIT

### CIRCUIT DESCRIPTION

When the ignition switch is turned ON, battery voltage is applied to terminal IGSW of the ECM. The ECM "MREL" output signal causes current to flow to the coil, closing the contacts of the EFI relay (Marked: EFI) and supplying power to terminal +B of the ECM.


If the ignition switch is turned OFF, the ECM holds the EFI relay ON for a maximum of 2 seconds to allow for the initial setting of the throttle valve.

### WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 INSPECT ECM (+B VOLTAGE)



- Turn the ignition switch ON.
- Check the voltage between of the E10 and E6 ECM connectors.

**Standard:**


Tester Connection	Specified Condition
E6-1 (+B) – E10-3 (E1)	9 to 14 V

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-34)**

NG

### 2 CHECK WIRE HARNESS (ECM – BODY GROUND)



- Disconnect the E10 ECM connector.
- Check the resistance of the wire harness side connectors.

**Standard:**


Tester Connection	Specified Condition
E10-3 (E1) – Body ground	Below 1 $\Omega$

NG

**REPAIR OR REPLACE HARNESS AND CONNECTOR**

OK

### 3 INSPECT ECM (IGSW VOLTAGE)



- Turn the ignition switch ON.
- Check the voltage of the E10 and E6 ECM connectors.


**Standard:**

Tester Connection	Specified Condition
E6-9 (IGSW) – E10-3 (E1)	9 to 14 V

OK

**Go to step 6**

NG

**4 CHECK FUSE (IGN)**


- (a) Remove the IGN fuse from the engine room J/B.  
 (b) Check the resistance of the IGN fuse.

**Standard: Below 1  $\Omega$**

**NG**

**REPLACE FUSE**

**OK**

**5 INSPECT IGNITION OR STARTER SWITCH ASSY**

- (a) Check the resistance of the ignition switch terminals.


**Standard:**

Switch Condition	Terminal Condition	Specified Condition
LOCK	6 (IG2) – 7 (AM2)	10 k $\Omega$ or higher
ON	6 (IG2) – 7 (AM2)	Below 1 $\Omega$

**NG**

**REPLACE IGNITION OR STARTER SWITCH ASSY**

**OK**

**CHECK AND REPAIR HARNESS AND CONNECTOR (BATTERY – IGNITION SWITCH, IGNITION SWITCH – ECM)****6 INSPECT ECM (MREL VOLTAGE)**

- (a) Turn the ignition switch ON.  
 (b) Measure the voltage of the E10 and E6 ECM connectors.

**Standard:**

Tester Connection	Specified Condition
E6-8 (MREL) – E10-3 (E1)	9 to 14 V


**NG**

**REPLACE ECM (See page 10-9)**

**OK**

7

CHECK FUSE (EFI)



- (a) Remove the EFI fuse from the engine room J/B.  
(b) Check the resistance of the EFI fuse.  
**Standard: Below 1 Ω**


NG

REPLACE FUSE

OK

8

INSPECT RELAY (EFI)



- (a) Remove the EFI relay from the engine room J/B.  
(b) Check the resistance of EFI the relay.  
**Standard:**

Tester Connection	Specified Condition
3 - 5	10 kΩ or higher
3 - 5	Below 1 Ω (when battery voltage is applied to terminals 1 and 2)


NG

REPLACE RELAY

OK

9

CHECK WIRE HARNESS (EFI RELAY – ECM, EFI RELAY – BODY GROUND)



- (a) Check the wire harness between the EFI relay and ECM.
- (1) Remove the EFI relay from the engine room J/B.
  - (2) Disconnect the E6 ECM connector.
  - (3) Check the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
J/B EFI relay terminal 1 – E6-8 (MREL)	Below 1 Ω
J/B EFI relay terminal 1 or E6-8 (MREL) – Body ground	10 kΩ or higher

- (b) Check the wire harness between the EFI relay and body ground.
- (1) Remove the EFI relay from the engine room J/B.
  - (2) Check the resistance of the wire harness side connector and the body ground.

Standard:

Tester Connection	Specified Condition
J/B EFI relay terminal 2 – Body ground	Below 1 Ω

OK

REPAIR OR REPLACE HARNESS AND CONNECTOR

NG

CHECK AND REPAIR HARNESS AND CONNECTOR (TERMINAL +B OF ECM – BATTERY POSITIVE TERMINAL)