


OIL PUMP ASSY (1AZ-FE)

REPLACEMENT

1705W-01

1. REMOVE CHAIN SUB-ASSY

(See [page 14-36](#))



2. REMOVE OIL PUMP ASSY

- (a) Remove 3 bolts and oil pump assembly.

3. INSTALL OIL PUMP ASSY

- (a) Place a new gasket on the cylinder block.
(b) Install the oil pump assembly with 3 bolts.

Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)