


# HEADLIGHT DOES NOT LIGHT UP

## WIRING DIAGRAM




H

E57887

INSPECTION PROCEDURE

1 INSPECT HEADLAMP RELAY



- (a) Inspect relay continuity.  
**Standard:**


Condition	Tester connection	Specified condition
Constant	1 – 2	Continuity
Apply B+ between terminal 1 and 2.	3 – 5	Continuity

NG REPLACE HEADLAMP RELAY

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR(BETWEEN INSTRUMENT PANEL J/B ASSY AND HEADLAMP RELAY)

2 INSPECT HEADLAMP DIMMER SWITCH ASSY(HEAD)



- (a) Inspect light control switch continuity.  
(1) Check that there is continuity between terminals at each switch position as shown in the chart.

Switch operation	Tester connection	Specified condition
OFF	–	No continuity
HEAD	13 – 16 – 14	Continuity

NG REPLACE HEADLAMP DIMMER SWITCH ASSY

OK

CHECK AND REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSY