

# AUDIO SYSTEM LOCATION

05D0U-10

Engine Room J/B, R/B

● ALT Fuse

● D.C.C Fuse

Front No.1

Speaker Assy RH

Front No.1 Speaker  
Assy LH

Rear Speaker Assy

Radio Receiver  
AssyFront No.2 Speaker  
Assy RHFront No.2 Speaker  
Assy LH

Driver Side J/B

● AM1 Fuse

● RAD No.1 Fuse

● RAD No.2 Fuse

● ACC Relay

● TAIL Relay

● PANEL Fuse

● Body ECU

Steering Pad Switch

Spiral Cable Sub-assy