

INTAKE AIR CONTROL SYSTEM (2AZ-FE (PZEV)) (From July, 2003)

1306I-02

ON-VEHICLE INSPECTION

1. CHECK INTAKE MANIFOLD RUNNER VALVE ASSY

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON.
- (c) Select IACV MOTOR from the ACTIVE TEST menu.
- (d) Check that the voltage output (IACV POSITION) in the DATA LIST indicates the standard value.

Standard:

Condition	Specified Condition
IAC valve open	3.0 to 4.2 V
IAC valve close	0.3 to 1.0 V