

# Power Seat

## Service Hints

### P16 Power Seat Control SW (Driver's Seat)

1-Ground : Always approx. 12 volts

4-Ground : Always continuity

### P17 Power Seat Control SW (Front Passenger's Seat)

1-Ground : Always approx. 12 volts

4-Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
P16	44 (LHD)	P19	54 (RHD)	P23	44 (LHD)
	54 (RHD)	P20	44 (LHD)		54 (RHD)
P17	44 (LHD)		54 (RHD)	P24	44 (LHD)
	54 (RHD)	P21	44 (LHD)		54 (RHD)
P18	44 (LHD)		54 (RHD)	P25	44 (LHD)
	54 (RHD)	P22	44 (LHD)		54 (RHD)
P19	44 (LHD)		54 (RHD)		

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2J	28	Floor Wire and Driver Side J/B (Lower Finish Panel)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IM3	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
IM5	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)
BD1	66 (LHD)	Floor Wire and Front Seat LH Wire (Under the Driver's Seat)
	78 (RHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Front Passenger's Seat)
BE1	66 (LHD)	Floor No.2 Wire and Front Seat RH Wire (Under the Front Passenger's Seat)
	78 (RHD)	Floor Wire and Front Seat RH Wire (Under the Driver's Seat)

## ▽ : Ground Points

Code	See Page	Ground Points Location
BO	64 (LHD)	Under the Driver's Seat
	76 (RHD)	Under the Front Passenger's Seat
BP	64 (LHD)	Under the Front Passenger's Seat
	76 (RHD)	Under the Driver's Seat

