


CRUISE MAIN INDICATOR LIGHT CIRCUIT

CIRCUIT DESCRIPTION

When the cruise control main switch is turned ON, CRUISE MAIN indicator light comes on.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF HAND-HELD TESTER

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the item "CCS INDICATOR" in the DATA LIST and read its value displayed on the hand-held tester.

OK:

ON: "CCS READY" ON


OFF: "CCS READY" OFF

OK

**PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN IN PROBLEM SYMPTOMS TABLE
(See page 05-2218)**

NG

2 INSPECT COMBINATION METER ASSY



- (a) Operation check
 - (1) Disconnect the connector from the combination meter.
 - (2) Connect the battery positive (+) lead to terminal C7-27 and the battery negative (-) lead to terminal C7-13.
 - (3) Check that the CRUISE MAIN indicator comes on.

OK:

Indicator comes on

NG

**GO TO COMBINATION METER SYSTEM
(See page 05-1999)**

OK

3 CHECK HARNESS AND CONNECTOR

- (a) Check for open and short circuit in the harness and the connector between terminal PI of ECM and the combination meter (See page 01-32).
- (b) Check for open and short circuit in the harness and the connector between the combination meter and the battery (See page 01-32).

NG

**REPAIR OR REPLACE HARNESS OR
CONNECTOR**

OK

CHECK AND REPLACE ECM