

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See page
Rear window defogger does not operate (Indicator lamp on)	1. DEF fuse (Instrument panel J/B)	68-1
	2. GAUGE 2 fuse (Instrument panel J/B)	68-1
	3. DEF relay (Instrument panel J/B)	70-19
	4. Rear window defogger wire	–
	5. Wire harness	–
	6. ECM (1AZ-FE)	05-21
	7. ECM (2AZ-FE)	05-150
	8. ECM (1MZ-FE)	05-308
Rear window defogger does not operate (Indicator lamp off)	1. HTR fuse (Instrument panel J/B)	68-1
	2. Defogger switch (Heater control housing)	05-694
	3. Wire harness	–
	4. Heater control base	05-694