

WINDOW DEFOGGER SYSTEM

PROBLEM SYMPTOMS TABLE

700BB-03

Symptom	Suspected Area	See page
Rear window defogger does not operate (Indicator lamp on)	1. DEF fuse (Instrument panel J/B) 2. GAUGE 2 fuse (Instrument panel J/B) 3. DEF relay (Instrument panel J/B) 4. Rear window defogger wire 5. Wire harness 6. Body ECU (2AZ-FE) 7. Body ECU (1MZ-FE)	68-1 68-1 70-22 – – – –
Rear window defogger does not operate (Indicator lamp off)	1. HTR fuse (Instrument panel J/B) 2. Defogger switch (Heater control housing) 3. Wire harness 4. Heater control base	68-1 05-1370 – 05-1370