

PROBLEM SYMPTOMS TABLE

When the malfunction is not confirmed in the DTC check and the problem still can not be confirmed in the basic inspection either, proceed to this problem symptoms table and troubleshoot according to the number given below.

Symptom	Suspected Area	See page
Engine does not crank (Does not start)	1. Starter 2. Starter relay 3. Neutral start switch	19-8 19-8 40-7
No initial combustion (Does not start)	1. ECM power source circuit 2. Ignition coil with igniter 3. Fuel control circuit 4. Injector circuit	05-278 05-236 05-271 05-189
No complete combustion (Does not start)	1. Ignition coil with igniter 2. Fuel control circuit 3. Injector circuit	05-236 05-271 05-189
Engine cranks normally (Difficult to start)	1. Starter signal circuit 2. Ignition coil with igniter 3. Spark plug 4. Compression 5. Injector circuit 6. Fuel control circuit	05-260 05-236 18-4 14-66 05-189 05-271
Cold engine (Difficult to start)	1. Starter signal circuit 2. Injector circuit 3. Ignition coil with igniter 4. Spark plug 5. Fuel control circuit	05-260 05-189 05-236 18-4 05-271
Hot engine (Difficult to start)	1. Starter signal circuit 2. Injector circuit 3. Ignition coil 4. Spark plug 5. Fuel control circuit	05-260 05-189 05-236 18-4 05-271
High engine idle speed (Poor idling)	1. ECM power source circuit 2. Back up power source circuit 3. Throttle position sensor circuit	05-278 05-276 05-188
Low engine idle speed (Poor idling)	1. Injector circuit 2. Back up power source circuit 3. Fuel control circuit	05-189 05-276 05-271
Rough idling (Poor idling)	1. Mass air flow meter circuit 2. Injector circuit 3. Fuel control circuit 4. Ignition coil with igniter 5. Compression	05-154 05-189 05-271 05-236 14-66
Hunting (Poor idling)	1. ECM power source circuit 2. Fuel control circuit 3. Mass air flow meter circuit 4. Throttle position sensor circuit	05-278 05-271 05-154 05-188
Hesitation/Poor acceleration (Poor drive ability)	1. Injector circuit 2. Ignition coil with igniter 3. Fuel control circuit	05-189 05-236 05-271
Muffler explosion after fire (Poor drive ability)	1. Ignition coil 2. Spark plug 3. Injector circuit	05-236 18-4 05-189
Surging (Poor drive ability)	1. Spark plug 2. Injector circuit	18-4 05-189
Engine stall (Soon after starting)	1. Fuel control circuit 2. Mass air flow meter circuit	05-271 05-154

Engine stall (After accelerator pedal depressed)	1. Injector circuit 2. Mass air flow meter circuit 3. ECM	18-4 05-154 01-31
Engine stall (After accelerator pedal released)	1. ECM 2. Mass air flow meter circuit	01-31 05-154
Engine stall (During A/C operation)	1. A/C signal circuit (Compressor circuit) 2. ECM	05-745 01-31