
















## DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed in the table below and proceed to the page given.

\*1  /  MIL light up

DTC No. (See Page)	Detection Item	Trouble Area	MIL *1	Memory
P0500/42 (05-64, 05-208 or 05-384)	Vehicle Speed Sensor Malfunction	<ul style="list-style-type: none"> <li>Combination meter</li> <li>Open or short in vehicle speed sensor circuit</li> <li>Vehicle speed sensor</li> <li>Skid control ECU</li> <li>ECM</li> </ul>		
P0710/38 (05-640)	Transmission Fluid Temp. Sensor Malfunction (ATF Temp. Sensor)	<ul style="list-style-type: none"> <li>Open in ATF temp. sensor circuit</li> <li>Transmission wire (ATF temperature sensor)</li> <li>ECM</li> </ul>		
P0711/38 (05-640)	Transmission Fluid Temp. Sensor Range/Performance Problem	<ul style="list-style-type: none"> <li>Transmission wire (ATF temperature sensor)</li> <li>ECM</li> </ul>		
P0750/62 (05-643)	Shift Solenoid A Malfunction (Shift Solenoid Valve SL1)	<ul style="list-style-type: none"> <li>Shift solenoid valve SL1 is stuck open or closed</li> <li>Valve body is blocked or stuck</li> <li>ECM</li> <li>Torque converter clutch</li> <li>Automatic transaxle</li> </ul>		
P0753/62 (05-648)	Shift Solenoid A Electrical Malfunction (Shift Solenoid Valve SL1)	<ul style="list-style-type: none"> <li>Open or short in shift solenoid valve SL1 circuit</li> <li>Shift solenoid valve SL1</li> <li>ECM</li> </ul>		
P0755/63 (05-643)	Shift Solenoid B Malfunction (Shift Solenoid Valve SL2)	<ul style="list-style-type: none"> <li>Shift solenoid valve SL2 is stuck open or closed</li> <li>Valve body is blocked or stuck</li> <li>ECM</li> <li>Torque converter clutch</li> <li>Automatic transaxle</li> </ul>		
P0758/63 (05-648)	Shift Solenoid B Malfunction (Shift Solenoid Valve SL2)	<ul style="list-style-type: none"> <li>Open or short in shift solenoid valve SL2 circuit</li> <li>Shift solenoid valve SL2</li> <li>ECM</li> </ul>		
P0765/65 (05-643)	Shift Solenoid D Malfunction (Shift Solenoid Valve S4)	<ul style="list-style-type: none"> <li>Shift solenoid valve S4 is stuck open or closed</li> <li>Valve body is blocked or stuck</li> <li>ECM</li> <li>Torque converter clutch</li> <li>Automatic transaxle</li> </ul>		
P0768/65 (05-648)	Shift Solenoid D Electrical Malfunction (Shift Solenoid Valve S4)	<ul style="list-style-type: none"> <li>Open or short in shift solenoid valve S4 circuit</li> <li>Shift solenoid valve S4</li> <li>ECM</li> </ul>		
P0770/64 (05-654)	Shift Solenoid E Malfunction (Shift Solenoid Valve DSL)	<ul style="list-style-type: none"> <li>Open or short in shift solenoid valve DSL circuit</li> <li>Shift solenoid valve DSL</li> <li>Valve body is blocked or stuck</li> <li>Lock-up clutch</li> <li>ECM</li> </ul>		
P0773/64 (05-658)	Shift Solenoid E Electrical Malfunction (Shift Solenoid Valve DSL)	<ul style="list-style-type: none"> <li>Open or short in shift solenoid valve DSL circuit</li> <li>Shift solenoid valve DSL</li> <li>ECM</li> </ul>		
P1520/95 (05-661)	Stop Light Switch Circuit	<ul style="list-style-type: none"> <li>Open or short in stop light switch circuit</li> <li>Stop lamp switch assy</li> <li>ECM</li> </ul>		
P1725/37 (05-663)	NT Revolution Sensor Circuit Malfunction (Input Turbine Speed Sensor)	<ul style="list-style-type: none"> <li>Open or short in speed sensor circuit</li> <li>Speed sensor (NT)</li> <li>ECM</li> </ul>		

P1730/67 (05-665)	NC Revolution Sensor Circuit Malfunction (Counter Gear Speed Sensor)	<ul style="list-style-type: none"> <li>• Open or short in speed sensor circuit</li> <li>• Speed sensor (NC)</li> <li>• ECM</li> </ul>	●	○
P1760/77 (05-668)	Linear Solenoid for Line Pres- sure Control Circuit Malfunction (Shift Solenoid Valve SLT)	<ul style="list-style-type: none"> <li>• Open or short in line pressure control solenoid (SLT) circuit</li> <li>• Line pressure control solenoid (SLT)</li> <li>• ECM</li> </ul>	●	○
P1780/97 (05-672)	Park/Neutral Position Switch Malfunction	<ul style="list-style-type: none"> <li>• Park/neutral position switch circuit</li> <li>• Park/neutral position switch assy</li> <li>• ECM</li> </ul>	●	○