


<b>DTC</b>	<b>C1241/41</b>	<b>LOW BATTERY POSITIVE VOLTAGE</b>
------------	-----------------	-------------------------------------

## CIRCUIT DESCRIPTION

This is the power source of the ECU, hence the actuators.


DTC No.	DTC Detecting Condition	Trouble Area
C1241/41	With vehicle speed to about 4 mph (6 km/h), battery voltage is less than 9.4 V at the time of non-operation of ABS control or less than 9.2 V at the time of operation of ABS control.	<ul style="list-style-type: none"><li>• Battery</li><li>• Charging system</li><li>• Power source circuit</li></ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 INSPECT FUSE(ECU-IG FUSE)



- (a) Remove the ECU-IG fuse from the driver side J/B.  
(b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
ECU-IG fuse	1 $\Omega$ or less (Continuity)

**NG****CHECK FOR SHORT IN ALL HARNESS AND CONNECTOR CONNECTED TO FUSE AND REPLACE FUSE****OK**

## 2 INSPECT BATTERY

- (a) Check the positive battery voltage.

**Standard:**

Tester Connection	Specified Condition
Battery terminal ( $\oplus - \ominus$ )	11 to 14 V

**NG****INSPECT CHARGING SYSTEM (See page 19-14 (2AZ-FE) OR 19-39 (1MZ-FE))****OK**

### 3 INSPECT SKID CONTROL ECU CONNECTOR(IG1 TERMINAL VOLTAGE)

#### WHEN USING HAND-HELD TESTER:


- Connect the hand-held tester to the DLC3.
- Start the engine.
- Select the DATA LIST mode on the hand-held tester.

Item	Measurement Item / Range (Display)	Normal Condition
IG VOLTAGE	ECU power supply voltage / NORMAL or TOO LOW	NORMAL: 9.8 V or over TOO LOW: Below 9.8 V

- Read the voltage condition output from the ECU displayed on the hand-held tester.

**Standard:**

**"Normal" is displayed.**



#### WHEN NOT USING HAND-HELD TESTER:

- Disconnect the skid control ECU connector.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

**Standard:**


Tester Connection	Specified Condition
S1-18 (IG1) – S1-4 (GND1)	10 to 14 V
S1-18 (IG1) – S1-1 (GND2)	10 to 14 V

**OK**

**REPLACE BRAKE ACTUATOR ASSY**  
(See page 32-58)

**NG**

### 4 INSPECT SKID CONTROL ECU CONNECTOR(GND TERMINAL CONTINUITY)



- Disconnect the skid control ECU connector.
- Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester Connection	Specified Condition
S1-4 (GND1) – Body ground	1 $\Omega$ or less
S1-1 (GND2) – Body ground	1 $\Omega$ or less

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR (SKID CONTROL ECU – BODY GROUND)**

**OK**

**CHECK AND REPAIR HARNESS OR CONNECTOR (SKID CONTROL ECU – BATTERY)**