


Removal & Installation and Disassembly & Reassembly


1. DRAIN COOLANT (See page 16-31)
2. REMOVE AIR CLEANER CAP WITH AIR CLEANER HOSE
 - (a) Disconnect the MAF meter connector.
 - (b) Disconnect the 4 vacuum hoses and the ventilation hose.
 - (c) Remove the air cleaner cap with the hose.
3. REMOVE FRONT SUSPENSION UPPER BRACE CENTER (W/ FRONT SUSPENSION BRACE UPPER CENTER)

4. REMOVE THROTTLE BODY ASSY

- (a) Disconnect the throttle position sensor connector.
- (b) Disconnect the throttle control motor connector.




- (c) Disconnect the 2 water by-pass hoses.



- (d) Remove the 2 bolts, 2 nuts, throttle body and gasket.


5. REMOVE E.F.I. THROTTLE POSITION SENSOR

- (a) Remove the 2 set screws and throttle position sensor.




6. INSTALL E.F.I. THROTTLE POSITION SENSOR

- (a) Check that the throttle valve is under the condition of the opener opening angle (about 7°).



- (b) Install the sensor to the place where is at 20 – 30° rotated to the right from the specified installation position.
- (c) Gradually turn sensor counterclockwise until it touches the throttle valve shaft, and temporarily tighten the 2 set screws.



- (d) Connect the throttle position sensor connector.
- (e) Connect the hand-held tester to the DLC3.
- (f) Turn the ignition switch ON.

NOTICE:

After turning the ignition switch ON, do not depress the accelerator pedal.

- (g) While reading the value of the throttle valve opening percentage (THROTTLE POS) of the CURRENT DATA, turn the throttle position sensor slowly to left and right and set the sensor at the center value of the standard value, and then tighten the screws.

Standard throttle valve opening percentage:

16.8 – 18.4 %

Torque: 2.0 N·m (20 kgf·cm, 18 in·lbf)

NOTICE:

After turning the ignition switch ON, do not depress the accelerator pedal.

- (h) Recheck throttle valve opening percentage.
If the throttle valve opening percentage is not as specified, repeat step (g).

- (i) Perform fully closed throttle valve by hand and check that the value of the throttle valve opening percentage (THROTTLE POS) of the CURRENT DATA stays with the standard value.

Standard throttle valve opening percentage:

10 – 14 %

If the throttle valve opening percentage is not as specified, repeat step (g) to (i).

- (j) Paint the 2 set screws.
- (k) Turn the ignition switch OFF.
- (l) Disconnect the hand-held tester from the DLC3.
- (m) Disconnect the throttle position sensor connector.

7. INSTALL THROTTLE BODY ASSY

- (a) Install a new gasket and the throttle body.

Torque: 20 N·m (199 kgf·cm, 14 ft·lbf)

8. INSTALL FRONT SUSPENSION UPPER BRACE CENTER (W/ FRONT SUSPENSION BRACE UPPER CENTER)

Torque: 80 N·m (816 kgf·cm, 59 ft·lbf)

- 9. ADD COOLANT ([See page 16-31](#))
- 10. CHECK ENGINE COOLANT LEAK ([See page 16-31](#))
- 11. INSPECT FUNCTION OF THROTTLE BODY ASSY
([See page 10-13](#))