


<b>DTC</b>	<b>C0226/21</b>	<b>SFR SOLENOID CIRCUIT</b>
<b>DTC</b>	<b>C0236/22</b>	<b>SFL SOLENOID CIRCUIT</b>
<b>DTC</b>	<b>C0246/23</b>	<b>SRR SOLENOID CIRCUIT</b>
<b>DTC</b>	<b>C0256/24</b>	<b>SRL SOLENOID CIRCUIT</b>
<b>DTC</b>	<b>C1225/25</b>	<b>SM SOLENOID CIRCUIT</b>
<b>DTC</b>	<b>C1226/26</b>	<b>SRM SOLENOID CIRCUIT</b>

## CIRCUIT DESCRIPTION

This solenoid goes on when signals are received from the ECU and controls the pressure acting on the wheel cylinders thus controlling the braking force.


DTC No.	DTC Detecting Condition	Trouble Area
C0226 / 21	Open or short circuit for SFRH or SFRR circuit continues for 0.05 sec. or more. (When the solenoid is normally ON.)	<ul style="list-style-type: none"> <li>• Brake actuator</li> <li>• SFRH or SFRR circuit</li> </ul>
C0236 / 22	Open or short circuit for SFLH or SFLR circuit continues for 0.05 sec. or more. (When the solenoid is normally ON.)	<ul style="list-style-type: none"> <li>• Brake actuator</li> <li>• SFLH or SFLR circuit</li> </ul>
C0246 / 23	Open or short circuit for SRRH or SRRR circuit continues for 0.05 sec. or more. (When the solenoid is normally ON.)	<ul style="list-style-type: none"> <li>• Brake actuator</li> <li>• SRRH or SRRR circuit</li> </ul>
C0256 / 24	Open or short circuit for SRLH or SRLR circuit continues for 0.05 sec. or more. (When the solenoid is normally ON.)	<ul style="list-style-type: none"> <li>• Brake actuator</li> <li>• SRLH or SRLR circuit</li> </ul>
C1225 / 25	Open or short circuit for SM1 or SM2 circuit continues for 0.05 sec. or more.	<ul style="list-style-type: none"> <li>• Brake actuator</li> <li>• SM1 or SM2 circuit</li> </ul>
C1226 / 26	Open or short circuit for SRM1 or SRM2 circuit continues for 0.05 sec. or more.	<ul style="list-style-type: none"> <li>• Brake actuator</li> <li>• SRM1 or SRM2 circuit</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 INSPECT BRAKE ACTUATOR ASSY



- (a) Disconnect the brake actuator connector.  
 (b) Check continuity between terminal BS and terminals SFRH, SFLH, SRRH, SRLH, SFRR, SFLR, SRRR and SRLR of brake actuator.

**OK: Continuity**

**HINT:**

Resistance of each solenoid at 25°C

SFRH, SFLH, SRRH, SRLH: 8.1 – 9.1 Ω

SFRR, SFLR, SRRR, SRLR: 4.0 – 4.6 Ω

- (c) Check continuity between terminals SM1+ and SM1- and terminals SM2+ and SM2- of brake actuator.

**OK: Continuity**

**HINT:**

Resistance of each solenoid: 8.1 – 9.1 Ω at 25°C

- (d) Check continuity between terminal BS and terminals SRM1 and SRM2 of brake actuator.

**OK: Continuity**

**HINT:**

Resistance of each solenoid at 25°C

SRM1, SRM2: 4.9 – 5.5 Ω

**NG**

**REPLACE BRAKE ACTUATOR ASSY**

**OK**

## 2 CHECK HARNESS AND CONNECTOR (BRAKE ACTUATOR ASSY - SKID CONTROL ECU ASSY) (See page 01-31)

**NG**

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

**OK**

## 3 CHECK SKID CONTROL ECU TERMINAL VOLTAGE (SR TERMINAL)

- (a) Remove the skid control ECU with connectors still connected.  
 (b) Turn the ignition switch ON, measure between terminal SR and GND.

**OK: 1 V or less**

**OK**

**CHECK AND REPAIR HARNESS AND ABS SOLENOID RELAY**

**NG**

4

RECONFIRM DTC(See page 05-451)

A	Malfunction Code
B	Normal Code

B

END

A

5

CHECK CONTACT CONDITION(EACH CONNECTION)

NG

CHECK AND REPAIR HARNESS AND CONNECTOR

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY