

DTCB0106/54OPEN IN P SQUIB CIRCUIT

CIRCUIT DESCRIPTION

The P squib circuit consists of the airbag sensor assy center and instr pnl pass l/door airbag assy. It causes the SRS to deploy when the SRS deployment conditions are satisfied. DTC B0106/54 is recorded when an open is detected in the P squib circuit.


DTC No.	DTC Detecting Condition	Trouble Area
B0106/54	<ul style="list-style-type: none">• Open circuit in P+ wire harness or P- wire harness of squib• P squib malfunction• Airbag sensor assy center malfunction	<ul style="list-style-type: none">• Instr pnl pass l/door airbag assy (P squib)• Airbag sensor assy center• Instrument panel wire

WIRING DIAGRAM

See page 05-787.

INSPECTION PROCEDURE

1CHECK P SQUIB CIRCUIT (AIRBAG SENSOR ASSY CENTER - INSTR PNL PASS L/DOOR AIRBAG ASSY)



- (a) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (b) Disconnect the connectors between the airbag sensor assy center and the instr pnl pass l/door airbag assy.
- (c) For the black connector (on the instr pnl pass l/door airbag assy side) between the airbag sensor assy center and the instr pnl pass l/door airbag assy, measure the resistance between P+ and P-.

OK:
Resistance: Below 1 Ω


NG

REPAIR OR REPLACE WIRE HARNESS (AIRBAG SENSOR ASSY CENTER - INSTR PNL PASS L/DOOR AIRBAG ASSY)

OK

2 CHECK AIR BAG SENSOR ASSY CENTER

SST 09843-18040



- Connect the connector to the airbag sensor assy center.
- Using a service wire, connect P+ and P- of the black connector (on the instr pni pass/door airbag assy side) between the airbag sensor assy center and the instr pni pass/door airbag assy.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See page 05-758).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page 05-758).


OK:**DTC B0106/54 is not output.****HINT:**

Codes other than code B0106/54 may be output at this time, but they are not relevant to this check.

NG**REPLACE AIR BAG SENSOR ASSY CENTER****OK**

3 CHECK P SQUIB

SST 09843-18040



- Turn the Ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the Instr PNL Pass L/door airbag Assy connectors.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Turn the Ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See page 05-758).
- Turn the Ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the Ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page 05-758).

OK:**DTC B0106/54 is not output.****HINT:**

Codes other than code B0106/54 may be output at this time, but they are not relevant to this check.

NG

REPLACE INSTR PNL PASS L/DOOR AIR BAG ASSY

OK

USE SIMULATION METHOD TO CHECK