

## DRIVER'S DOOR WINDOW DOES NOT GO DOWN ALTHOUGH FOREIGN OBJECTS ARE CAUGHT IN BETWEEN

HINT:

In the LHD vehicle, work in the same procedure as in the RHD vehicle.

### CIRCUIT DESCRIPTION

The power window regulator master switch assembly controls the driver's power window motor. The jam protection functions only within the operation range of the jam protection during the AUTO UP and MANUAL UP operation.

### INSPECTION PROCEDURE

#### 1 CHECK POWER WINDOW REGULATOR MASTER SWITCH ASSY

- (a) The AUTO UP or AUTO DOWN operation works with the ignition switch ON.

NG

GO TO FLOWCHART (See page 05-1156)

OK

#### 2 CHECK JAM PROTECTION FUNCTION OPERATING RANGE

- (a) Check that the jam protection function does not operate within 4 mm (0.16 in.) before the full-closed position of the door glass.

OK

NORMAL

NG

#### 3 RESET POWER WINDOW REGULATOR MOTOR

- (a) Reset the power window regulator motor (See page 75-8).  
(b) Check if the door glass operates normally.

HINT:

Unless the door glass operates normally, make an adjustment of the door glass assembled condition and then check the operation once again.

OK

NORMAL

NG

REPLACE POWER WINDOW REGULATOR MASTER SWITCH ASSY