

PROBLEM SYMPTOMS TABLE

HINT:

Proceed to the troubleshooting of each circuit in the table below.

| Symptom | Suspected Area | See page |
|---|---|-------------------------|
| • When the ignition switch is in the ON position, the SRS warning light sometimes comes on after approximately 6 seconds. | • SRS warning light circuit malfunction (Always comes on, when DTC is not output). | 05-1777 |
| • SRS warning light always comes on even when DTC is not output. | • SRS warning light circuit malfunction (Always comes on, when DTC is not output). | 05-1777 |
| • With the ignition switch in the ON position, the SRS warning light does not come on. | • SRS warning light circuit malfunction (Does not come on, when ignition switch is turned to the ON position). | 05-1781 |
| • Although the SRS warning light operates normally, DTC or a normal system code is not displayed. | • TC Terminal circuit | 05-1783 |
| • Although terminals TC and CG are not connected, DTC or a normal system code is displayed. | • TC Terminal circuit | 05-1783 |