

<b>DTC</b>	<b>B1800/51</b>	<b>SHORT IN D SQUIB CIRCUIT</b>
<b>DTC</b>	<b>B1801/51</b>	<b>OPEN IN D SQUIB CIRCUIT</b>
<b>DTC</b>	<b>B1802/51</b>	<b>SHORT IN D SQUIB CIRCUIT (TO GROUND)</b>
<b>DTC</b>	<b>B1803/51</b>	<b>SHORT IN D SQUIB CIRCUIT (TO B+)</b>

## CIRCUIT DESCRIPTION


The D squib circuit consists of the airbag sensor assy center, the spiral cable sub-assy and the horn button assy.

The circuit instructs the SRS to deploy when deployment conditions are met.

These DTCs are recorded when a malfunction is detected in the D squib circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1800/51	<ul style="list-style-type: none"> <li>• The airbag sensor assy center receives a line short circuit signal 5 times in the D squib circuit during primary check.</li> <li>• D squib malfunction</li> <li>• Spiral cable sub-assy malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>
B1801/51	<ul style="list-style-type: none"> <li>• The airbag sensor assy center receives an open circuit signal in the D squib circuit for 2 seconds.</li> <li>• D squib malfunction</li> <li>• Spiral cable sub-assy malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>
B1802/51	<ul style="list-style-type: none"> <li>• The airbag sensor assy center receives a short circuit to ground signal in the D squib circuit for 0.5 second.</li> <li>• D squib malfunction</li> <li>• Spiral cable sub-assy malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>
B1803/51	<ul style="list-style-type: none"> <li>• The airbag sensor assy center receives a short circuit to B+ signal in the D squib circuit for 0.5 second.</li> <li>• D squib malfunction</li> <li>• Spiral cable sub-assy malfunction</li> <li>• Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>• Horn button assy (D squib)</li> <li>• Spiral cable sub-assy</li> <li>• Airbag sensor assy center</li> <li>• Instrument panel wire</li> </ul>

WIRING DIAGRAM



## INSPECTION PROCEDURE

### CAUTION:

Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the airbag sensor Assy center.
- (d) Disconnect the connectors from the horn button Assy.
- (e) Disconnect the connectors from the front passenger airbag Assy.
- (f) Disconnect the connector from the front seat airbag Assy LH.
- (g) Disconnect the connector from the front seat airbag Assy RH.
- (h) w/ Curtain shield airbag:  
Disconnect the connector from the curtain shield airbag Assy LH.
- (i) w/ Curtain shield airbag:  
Disconnect the connector from the curtain shield airbag Assy RH.
- (j) Disconnect the connector from the front seat outer belt Assy LH.
- (k) Disconnect the connector from the front seat outer belt Assy RH.

### 1 CHECK READ METHOD OF DTC

- (a) Proceed to each step according to DTC readings.
  - (1) If using the intelligent tester II (read the 5-digit of DTC):  
Using the intelligent tester II, check the DTC (see page 05-16).

#### Result:

DTC B1800 is output.	A
DTC B1801 is output.	B
DTC B1802 is output.	C
DTC B1803 is output.	D

- (2) If not using the intelligent tester II (read the 2-digit of DTC):  
Check the DTC (see page 05-16).

#### Result:

DTC 51 is output.	E
-------------------	---

**B** Go to step 4

**C** Go to step 5

**D** Go to step 6

**E** Go to step 7

**A**

2 CHECK CONNECTOR

(a) Check that the spiral cable sub-assy connectors (on the horn button assy side) are not damaged.  
OK:


The lock button is not disengaged, or the claw of the lock is not deformed or damaged.

NG

REPLACE SPIRAL CABLE SUB-ASSY  
(SEE PAGE 60-28)

OK

3 CHECK D SQUIB CIRCUIT (SHORT)



- (a) Release the activation prevention mechanism built into connector "B" (see page 05-10).
- (b) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
D+ - D-	Always	1 MΩ or Higher

NG

Go to step 13

OK


GO TO STEP 10

**4 CHECK D SQUIB CIRCUIT (OPEN)**

- (a) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - D-	Always	Below 1 $\Omega$

**NG****Go to step 15****OK****GO TO STEP 11****5 CHECK D SQUIB CIRCUIT (TO GROUND)**


- (a) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - Body ground	Always	1 M $\Omega$ or Higher
D- - Body ground	Always	1 M $\Omega$ or Higher

**NG****Go to step 17****OK****GO TO STEP 11**

**6 CHECK D SQUIB CIRCUIT (TO B+)**



- (a) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - Body ground	Ignition switch ON	Below 1 V
D- - Body ground	Ignition switch ON	Below 1 V

**NG**

**Go to step 19**

**OK**

**GO TO STEP 11**

**7 CHECK CONNECTOR**

- (a) Check that the spiral cable sub-assy connectors (on the horn button assy side) are not damaged.


**OK:**

The lock button is not disengaged, or the claw of the lock is not deformed or damaged.

**NG**

**REPLACE SPIRAL CABLE SUB-ASSY**  
(SEE PAGE 60-28)

**OK**

**8 CHECK D SQUIB CIRCUIT**

- (a) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.  
 (b) Turn the ignition switch to the ON position.  
 (c) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - Body ground	Ignition switch ON	Below 1 V
D- - Body ground	Ignition switch ON	Below 1 V

- (d) Turn the ignition switch to the LOCK position.  
 (e) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.  
 (f) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - D-	Always	Below 1 Ω
D+ - Body ground	Always	1 MΩ or Higher
D- - Body ground	Always	1 MΩ or Higher

- (g) Release the activation prevention mechanism built into connector "B" (see page 05-10).  
 (h) Measure the resistance according to the value(s) in the table below.

**Standard:**


Tester connection	Condition	Specified condition
D+ - D-	Always	1 MΩ or Higher

**NG**

**Go to step 21**

**OK**

## 9 REPLACE HORN BUTTON ASSY (DISQUIB)



(a) Replace the horn button assy (see page 60-19)

HINT:

Perform the inspection using parts from a normal vehicle if possible.

- (b) Connect the connectors to the airbag sensor assy center.
- (c) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (d) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (e) Clear the DTCs stored in memory (see page 05-16)
- (f) Turn the ignition switch to the LOCK position.
- (g) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (h) Check the DTCs (see page 05-16)

**OK:**

**DTC 51 is not output.**

HINT:

Codes other than code 51 may be output at this time, but they are not related to this check.


**NG**

**REPLACE AIR BAG SENSOR ASSY CENTER  
(SEE PAGE 60-40)**

**OK**

**END**



**10 CHECK AIR BAG SENSOR ASSY CENTER**

- Connect the connectors to the airbag sensor assy center.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Clear the DTCs stored in memory (see page 05-16).
- Turn the ignition switch to the LOCK position.
- Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- Check the DTCs (see page 05-16).

**OK:****DTC B1800 is not output.****HINT:**


Codes other than code B1800 may be output at this time, but they are not related to this check.

**NG**

**REPLACE AIR BAG SENSOR ASSY CENTER**  
(SEE PAGE 60-40)

**OK****GO TO STEP 12**

# 11 CHECK AIR BAG SENSOR ASSY CENTER



- From the step 6:  
Turn the ignition switch to the LOCK position.
- From the step 6:  
Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Connect the connectors to the airbag sensor Assy center.
- Using a service wire, connect D+ and D- of connector "E".

## NOTICE:

- Twist the end of the service wire in order to insert it into the connector.
  - Do not forcibly insert the twisted service wire into the terminals of the connector when connecting.
- Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
  - Turn the ignition switch to the ON position, and wait for at least 60 seconds.
  - Clear the DTCs stored in memory (see page 05-16).
  - Turn the ignition switch to the LOCK position.
  - Turn the ignition switch to the ON position, and wait for at least 60 seconds.
  - Check the DTCs (see page 05-16).

## OK:

**DTC B1801, B1802 or B1803 is not output.**


## HINT:

Codes other than code B1801, B1802 and B1803 may be output at this time, but they are not related to this check.

**NG**

**REPLACE AIR BAG SENSOR ASSY CENTER  
(SEE PAGE 60-40)**

**OK**

**12 CHECK HORN BUTTON ASSY (DISQUIB)**

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) From the step 11  
Disconnect the service wire from connector "E".
- (d) Connect the connectors to the horn button assy.
- (e) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Clear the DTCs stored in memory (see page 05-16).
- (h) Turn the ignition switch to the LOCK position.
- (i) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (j) Check the DTCs (see page 05-16).

**OK:**

**DTC B1800, B1801, B1802 or B1803 is not output.**

**HINT:**


Codes other than code B1800, B1801, B1802 and B1803 may be output at this time, but they are not related to this check.

**NG**

**REPLACE HORN BUTTON ASSY  
(SEE PAGE 60-19)**

**OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-10)****HINT:**

- Perform the simulation method by selecting the check mode with the intelligent tester II (see page 05-19).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-19).

**13 CHECK INSTRUMENT PANEL WIRE (SHORT)**

(a) Disconnect the instrument panel wire connector from the spiral cable sub-assy.

HINT:

The activation prevention mechanism of connector "B" has already been released.

(b) Measure the resistance according to the value(s) in the table below.


**Standard:**

Tester connection	Condition	Specified condition
A31-1 (D+) - A31-2 (D-)	Always	1 MΩ or Higher

NG

**REPAIR OR REPLACE INSTRUMENT PANEL WIRE**

OK

**14 CHECK SPIRAL CABLE SUB-ASSY (SHORT)**

(a) Release the activation prevention mechanism built into connector "D" (see page 05-10).

(b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - D-	Always	1 MΩ or Higher

NG


**REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-28)**

OK

**USE SIMULATION METHOD TO CHECK (SEE PAGE 05-10)**

HINT:


- Perform the simulation method by selecting the check mode with the Intelligent Tester II (see page 05-19).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05-19).

**15 CHECK INSTRUMENT PANEL WIRE (OPEN)**

- (a) Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
A31-1 (D+) - A31-2 (D-)	Always	Below 1 $\Omega$

**NG****REPAIR OR REPLACE INSTRUMENT PANEL WIRE****OK****16 CHECK SPIRAL CABLE SUB-ASSY (OPEN)**

- (a) Measure the resistance according to the value(s) in the table below.


**Standard:**

Tester connection	Condition	Specified condition
D+ - D-	Always	Below 1 $\Omega$

**NG****REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-28)****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-10)****HINT:**

- Perform the simulation method by selecting the check mode with the Intelligent Tester II (see page 05-19).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05-19).

## 17 CHECK INSTRUMENT PANEL WIRE (TO GROUND)



- (a) Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- (b) Measure the resistance according to the value(s) in the table below.

### Standard:


Tester connection	Condition	Specified condition
A31-1 (D+) - Body ground	Always	1 MΩ or Higher
A31-2 (D-) - Body ground	Always	1 MΩ or Higher

NG

**REPAIR OR REPLACE INSTRUMENT PANEL WIRE**

OK

## 18 CHECK SPIRAL CABLE SUB-ASSY (TO GROUND)



- (a) Measure the resistance according to the value(s) in the table below.

### Standard:

Tester connection	Condition	Specified condition
D+ - Body ground	Always	1 MΩ or Higher
D- - Body ground	Always	1 MΩ or Higher

NG


**REPLACE SPIRAL CABLE SUB-ASSY  
(SEE PAGE 60-28)**

OK

## USE SIMULATION METHOD TO CHECK (SEE PAGE 05-10)

### HINT:


- Perform the simulation method by selecting the check mode with the Intelligent Tester II (see page 05-19).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05-19).

**19 CHECK INSTRUMENT PANEL WIRE (TO B+)**

- Turn the Ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Disconnect the instrument panel wire connector from the spiral cable sub-assy.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 2 seconds.
- Turn the Ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
A31-1 (D+) - Body ground	Ignition switch ON	Below 1 V
A31-2 (D-) - Body ground	Ignition switch ON	Below 1 V

**NG****REPAIR OR REPLACE INSTRUMENT PANEL WIRE****OK****20 CHECK SPIRAL CABLE SUB-ASSY (TO B+)**

- Measure the voltage according to the value(s) in the table below when the ignition switch is in the ON position.

**Standard:**

Tester connection	Condition	Specified condition
D+ - Body ground	Ignition switch ON	Below 1 V
D- - Body ground	Ignition switch ON	Below 1 V

**NG****REPLACE SPIRAL CABLE SUB-ASSY (SEE PAGE 60-28)****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-10)****HINT:**

- Perform the simulation method by selecting the check mode with the intelligent tester (see page 05-19).
- After selecting the check mode, perform the simulation method by wiggling each connector of the airbag system or driving the vehicle on a city or rough road (see page 05-19).

21 ☐

- Standard:**

- (f) Turn the ignition switch to the LOCK position.
- (g) Disconnect the negative (–) terminal cable from the battery, and wait for at least 90 seconds.
- (h) Measure the resistance according to the value(s) in the table below.

- Standard:**


- Release the activation prevention mechanism built into connector "B" [\[see page 05-10\]](#)
- Measure the resistance according to the value(s) in the table below.

- Standard:**

NG

**OK**



**22 CHECK SPIRAL CABLE SUB-ASSY**

- Connect the negative (-) terminal cable from the battery, and wait for at least 2 seconds.
- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - Body Ground	Ignition switch ON	Below 1 V
D- - Body Ground	Ignition switch ON	Below 1 V

- Turn the ignition switch to the LOCK position.
- Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - D-	Always	Below 1 Ω
D+ - Body Ground	Always	1 MΩ or Higher
D- - Body Ground	Always	1 MΩ or Higher

- Release the activation prevention mechanism built into connector "D" (see page 05-10).
- Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
D+ - D-	Always	1 MΩ or Higher

**NG****REPLACE SPIRAL CABLE SUB-ASSY  
(SEE PAGE 60-28)****OK****USE SIMULATION METHOD TO CHECK (SEE PAGE 05-10)****HINT:**

- Perform the simulation method by selecting the check mode with the intelligent tester (see page 05-19).
- After selecting the check mode, perform the simulation method by wiggling each connector of the air-bag system or driving the vehicle on a city or rough road (see page 05-19).