

<b>DTC</b>	<b>C1210/36</b>	<b>ZERO POINT CALIBRATION OF YAW RATE SENSOR UNDONE</b>
------------	-----------------	---


<b>DTC</b>	<b>C1233/33</b>	<b>OPEN OR SHORT CIRCUIT IN YAW RATE SENSOR CIRCUIT</b>
------------	-----------------	---

<b>DTC</b>	<b>C1234/34</b>	<b>MALFUNCTION IN YAW RATE SENSOR</b>
------------	-----------------	---------------------------------------

## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1210 / 36	<ol style="list-style-type: none"> <li>After ECU was replaced, when the shift lever was moved other than to P position within 15 sec. soon after ECU terminal IG1 become ON for the first time.</li> <li>When the yaw rate sensor zero point recorded in ECU is deleted.</li> </ol>	<ul style="list-style-type: none"> <li>Yaw rate sensor</li> <li>Yaw rate sensor circuit</li> <li>P position switch circuit</li> </ul>
C1233/33	<p>Detection of any of conditions 1. through 4.:</p> <ol style="list-style-type: none"> <li>When the ECU IG1 terminal voltage is 9.5 to 17.2 V, the yaw rate sensor voltage is out of the range from 0.25 to 4.75 V for 1 sec. or more.</li> <li>The yaw rate sensor open circuit detect signal is ON for 1 sec. or more.</li> <li>The yaw rate sensor power source voltage is out of the range from 4.4 to 5.6 V for 1 sec. or more.</li> <li>Momentary open circuit of the yaw rate sensor signal occurs 10 times or more.</li> </ol>	<ul style="list-style-type: none"> <li>Yaw rate sensor</li> <li>Yaw rate sensor circuit</li> </ul>
C1234/34	When the yaw rate sensor VYS terminal voltage is 4.4 to 5.6 V, YD malfunction signal of the yaw rate sensor is ON for 5 sec. or more.	

WIRING DIAGRAM



INSPECTION PROCEDURE

1. PERFORM ZERO POINT CALIBRATION OF YAW RATE SENSOR (See page 05-511)




2. RECONFIRM DTC (See page 05-511)

A	Malfunction Code
B	Normal Code

B END



### 3 INSPECT YAWRATE SENSOR




#### IN CASE OF USING HAND-HELD TESTER:

- Remove the console box.
- Remove the yaw rate sensor with the connector still connected to it.
- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the DATALIST mode on the hand-held tester.
- Check that the yaw rate sensor value of the yaw rate sensor observed in the hand-held tester is changing: Place the yaw rate sensor vertically to the ground and turn the sensor pivoted on its center.

#### OK:

**Yaw rate value must be changing. (Reference)**

**When the yaw rate sensor is stationary output value:**  
 $\pm 4 \text{ deg/s}$ .



#### IN CASE OF NOT USING HAND-HELD TESTER:

- Remove the console box then remove the yaw rate sensor with the connector still connected to it.
- Turn the ignition switch ON.
- Measure voltage between terminals YAW2 (1) -GYAW (5), and terminals YD (6)-GYAW (5) of the yaw rate sensor.

#### OK:


Terminals 1 and 5 (YAW2-GYAW)	About 2.42-2.58 V
Terminals 6 and 5 (YD-GYAW)	About 4.5-5.3 V

**NG**

**REPLACE YAWRATE SENSOR**

**OK**

### 4 CHECK SKID CONTROL ECU TERMINAL VOLTAGE(YD TERMINAL)



- Remove the skid control ECU with connector still connected.
- Turn the ignition switch ON.
- Measure voltage between terminals YD and GND of skid control ECU.

**OK: 4.5 - 5.3 V**

**OK**

**CHECK AND REPLACE SKID CONTROL ECU ASSY**

**NG**

5

CHECK HARNESS AND CONNECTOR (YAW RATE SENSOR - SKID CONTROL ECU ASSY) (See page 01-31)

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

CHECK AND REPLACE SKID CONTROL ECU ASSY