



# MALFUNCTION IN OUTSIDE TEMPERATURE DISPLAY

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 CHECK CLOCK ASSY



- (a) Check voltage.
- (1) Remove the clock assy with connector still connected.
  - (2) Turn the ignition switch to ON.
  - (3) Measure voltage between terminals 2 (SG) and 3 (TH+) of clock assy connector at each temperature.

#### Voltage:

at 25 °C (77 °F): 1.35 – 1.75 V

at 40 °C (104 °F): 0.85 – 1.25 V


#### HINT:

As the temperature increases, the voltage decreases.

OK

CHECK AND REPLACE CLOCK ASSY

NG

**2 INSPECT COOLER (AMBIENT TEMP. SENSOR) THERMISTOR**

- (a) Disconnect cooler (ambient temp. sensor) thermistor connector.
- (b) Measure resistance between terminals 1 and 2 of cooler (ambient temperature sensor) thermistor connector at each temperature.

**Resistance:****at 25 °C (77 °F): 1.6 – 1.8 kΩ****at 40 °C (104 °F): 0.5 – 0.7 kΩ****HINT:**

As the temperature increases, the resistance decreases.

**NG****REPLACE COOLER (AMBIENT TEMP. SENSOR) THERMISTOR****OK****REPAIR OR REPLACE HARNESS OR CONNECTOR**