


## POWER SOURCE CIRCUIT (RADIO AND NAVIGATION ASSY)

### CIRCUIT DESCRIPTION


This circuit provides the power to the radio and navigation assy.

### WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT RADIO AND NAVIGATION ASSY(+B, ACC, GND)



- (a) Disconnect the radio and navigation assy connector R4.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
GND – Body ground	Always	Below 1 $\Omega$

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
+B – GND	Always	10 to 14 V
ACC – GND	Ignition SW ACC	10 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE OR DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05-1914 OR 05-1910)