

PROBLEM SYMPTOMS TABLE

RADIO RECEIVER ASSY

HINT:

Inspect the "Fuse" and "Relay" before confirming the suspected area as shown in the table below.

Symptom	Suspected Area	See page
Pressing power switch does not start system.	1. Power source circuit (radio receiver assy) 2. Radio receiver assy	05-1842 67-4
Radio receiver cannot be dimmed in night time.	1. Illumination circuit 2. Radio receiver assy	05-1850 67-4
A audio system cannot be operated.	1. Steering pad switch circuit 2. Radio receiver assy	05-1858 67-4
No sound can be heard (Separate type amplifier).	1. Power source circuit (radio receiver assy) 2. Power source circuit (stereo component amplifier assy) 3. AMP sound signal circuit 4. Speaker circuit 5. AMP mute signal circuit 6. Stereo component amplifier assy 7. Radio receiver assy	05-1842 05-1846 05-1870 05-1862 05-1867 67-18 67-4
No sound can be heard (Built-in type amplifier).	1. Power source circuit (radio receiver assy) 2. Speaker circuit 3. Radio receiver assy	05-1842 05-1862 67-4
Sound quality is bad in all modes (volume is too low). (Separate type amplifier)	1. Power source circuit (radio receiver assy) 2. Power source circuit (stereo component amplifier assy) 3. Speaker circuit 4. AMP sound signal circuit 5. Sound quality is bad in all modes (volume is too low)	05-1842 05-1846 05-1862 05-1870 05-1874
Sound quality is bad in all modes (volume is too low). (Built-in type amplifier)	1. Power source circuit (radio receiver assy) 2. Speaker circuit 3. Sound quality is bad in all modes (volume is too low)	05-1842 05-1862 05-1874
Beep sound cannot be heard.	1. Beep sound signal circuit 2. Radio receiver assy 3. Stereo component amplifier assy	05-1872 67-4 67-18
Noise occurs.	–	05-1875
Radio broadcast cannot be received (bad reception).	–	05-1875
CD cannot be inserted or is ejected right after insertion.	1. Power source circuit (radio receiver assy) 2. CD cannot be inserted or is ejected right after insertion	05-1842 05-1878
CD cannot be ejected.	1. Power source circuit (radio receiver assy) 2. CD cannot be ejected	05-1842 05-1880
Sound quality is bad only when playing CD (volume is too low).	–	05-1881
CD sound skips.	–	05-1882
Cassette tape cannot be inserted or played.	1. Power source circuit (radio receiver assy) 2. Cassette tape cannot be inserted or played	05-1842 05-1884
Cassette tape cannot be ejected.	1. Power source circuit (radio receiver assy) 2. Cassette tape cannot be ejected	05-1842 05-1885
Sound quality is bad only when playing tape.	–	05-1886
Tape is tangled due to incorrect tape speed or auto-reverse mal-function.	–	05-1887

STEERING PAD SWITCH

Symptom	Suspected Area	See page
A audio system cannot be operated with steering pad switch.	1. Steering pad switch circuit 2. Radio receiver assy	05-1858 67-4
Illumination for steering pad switch does not come on with TAIL switch on.	1. Illumination circuit 2. Radio receiver assy	05-1850 67-4