

KEY REMINDER BUZZER DOES NOT SOUND

INSPECTION PROCEDURE

1 CHECK BUZZER


(a) Check that key reminder warning buzzer sound.

NG

CHECK AND REPLACE COMBINATION METER ASSY

OK

2 CHECK COMBINATION METER ASSY



(a) Check voltage.

- (1) Remove the combination meter assy with connectors still connected.
- (2) Measure the voltage between terminal C8-11 of combination meter and body ground.

Standard voltage:

Condition	Voltage (V)
Insert the key to key cylinder, ignition switch is at ON position and driver door open	10 - 14
Insert the key to key cylinder, ignition switch is at OFF position and driver door open	Below 1

OK

REPLACE COMBINATION METER ASSY

NG

3 INSPECT FRONT DOOR COURTESY LAMP SWITCH ASSY (See page 65-3)

NG

REPLACE FRONT DOOR COURTESY LAMP SWITCH ASSY

OK

4 INSPECT UN-LOCK WARNING SWITCH ASSY (See page 73-19)

NG

REPLACE UN-LOCK WARNING SWITCH ASSY

OK

5	CHECK HARNESS AND CONNECTOR(BETWEEN BODY ECU AND FRONT DOOR COURTESY LAMP SWITCH)
----------	--

NG

REPAIR OR CONNECTOR	REPLACE HARNESS OR
--------------------------------	---------------------------

OK

6	CHECK HARNESS AND CONNECTOR(BETWEEN BODY ECU AND KEY UNLOCK WARNING SWITCH)
----------	--

NG

REPAIR OR CONNECTOR	REPLACE HARNESS OR
--------------------------------	---------------------------

OK

CHECK AND REPLACE MULTIPLEX NETWORK BODY ECU
