

## Service Hints

### DEF Relay

5-3 : Closed with the ignition SW at on and rear window defogger SW (A/C control assembly) on

### M1, M2 Mirror Heater LH, RH

6-Ground : Approx. 12 volts with the rear window defogger SW (A/C control assembly) on

7-Ground : Always continuity

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A17	40 (LHD)	M2	43 (LHD)	R18	B
	50 (RHD)		53 (RHD)		
M1	43 (LHD)	R17	A		
	53 (RHD)				

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2C	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2J	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2K		
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2R		
2S		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	60 (LHD)	Front Door LH Wire and Floor Wire (Left Kick Panel)
IB1	72 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IL1	62 (LHD)	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IN1	74 (RHD)	Front Door RH Wire and Floor Wire (Right Kick Panel)

## ▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IN	72 (RHD)	Instrument Panel Reinforcement RH
BO	64 (LHD)	Under the Driver's Seat
BP	76 (RHD)	
BT	64 (LHD)	Rear Quarter Panel RH
	76 (RHD)	Rear Quarter Panel LH