

Service Hints

Body ECU

- 9-Ground : Approx. 12 volts with ignition SW at ON or ST position
- 12, 24-Ground : Always continuity
- 1-Ground : Always approx. 12 volts

D6, D7, D8, D9 Door Courtesy SW Front LH, RH, Rear LH, RH

- 1-Ground : Closed with each of the door

○ : Parts Location

Code		See Page	Code	See Page	Code	See Page
B5	A	40 (LHD)	D8	42 (LHD)	L4	53 (RHD)
		50 (RHD)		52 (RHD)	L5	43 (LHD)
B7	C	40 (LHD)	D9	42 (LHD)	M4	53 (RHD)
		50 (RHD)		52 (RHD)		43 (LHD)
C7	A	40 (LHD)	I13	51 (RHD)	N4	53 (RHD)
		50 (RHD)	I14	41 (LHD)		43 (LHD)
C8	B	40 (LHD)		51 (RHD)	V7	53 (RHD)
		50 (RHD)	I17	42 (LHD)		43 (LHD)
D6		42 (LHD)		52 (RHD)	V8	53 (RHD)
		52 (RHD)	J12	51 (RHD)		43 (LHD)
D7		42 (LHD)	J13	51 (RHD)		53 (RHD)
		52 (RHD)	L4	43 (LHD)		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	28	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2Q		
2R		
2S		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC2	60 (LHD)	Instrument Panel Wire and Floor Wire (Left Kick Panel)
	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IC3	72 (RHD)	Instrument Panel Wire and Floor Wire (Right Kick Panel)
IE1	60 (LHD)	Instrument Panel Wire and Roof Wire (Inside of Front Left Pillar)
	72 (RHD)	Instrument Panel Wire and Roof Wire (Inside of Front Right Pillar)
IM3	62 (LHD)	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
	74 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Left Kick Panel)

▽ : Ground Points

Code	See Page	Ground Points Location
II	60 (LHD)	Cowl Side Panel LH
IJ	60 (LHD)	Instrument Panel Brace LH
	72 (RHD)	Instrument Panel Reinforcement LH
IK	72 (RHD)	Instrument Panel Brace LH
IM	60 (LHD)	Instrument Panel Reinforcement RH
IN	72 (RHD)	

Interior Light



: Splice Points

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B1	64 (LHD)	Roof Wire	B5	64 (LHD)	Floor Wire
	76 (RHD)			76 (RHD)	

