


## TC TERMINAL CIRCUIT


### CIRCUIT DESCRIPTION

Connecting terminals Tc and CG of the DLC3 causes ECU to display the DTCs by blinking the ABS warning light.

### WIRING DIAGRAM



2AZ



N


F49678

## INSPECTION PROCEDURE

### NOTICE:

When replacing the brake actuator assy, perform zero point calibration (see page 05-987).

### 1 INSPECT DLC3 TERMINAL VOLTAGE(Tc TERMINAL)



- Turn the ignition switch to the ON position.
- Measure the voltage according to the value(s) in the table below.

#### Standard:


Tester Connection	Specified Condition
D3-13 (TC) - D3-4 (CG)	10 to 14 V

NG

Go to step 3

OK

### 2 CHECK HARNESS AND CONNECTOR(ECM - SKID CONTROL ECU)



#### 1MZ, 3MZ:

- Disconnect the skid control ECU connector S1 and ECM connector E6.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

Tester Connection	Specified Condition
S1-8 (TRC+) - E6-25 (TRC+)	Below 1 $\Omega$
S1-22 (TRC-) - E6-31 (TRC-)	Below 1 $\Omega$
S1-9 (ENG+) - E6-24 (ENG+)	Below 1 $\Omega$
S1-23 (ENG-) - E6-30 (ENG-)	Below 1 $\Omega$

- Measure the resistance according to the value(s) in the table below.

#### Standard:

Tester Connection	Specified Condition
S1-8 (TRC+) - Body ground	10 k $\Omega$ or higher
S1-22 (TRC-) - Body ground	10 k $\Omega$ or higher
S1-9 (ENG+) - Body ground	10 k $\Omega$ or higher
S1-23 (ENG-) - Body ground	10 k $\Omega$ or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

2AZ:

- (a) Check CAN communication system (see page 05-2174).  
OK:CAN communication system is normal.


NG

CHECK CAN COMMUNICATION SYSTEM  
(SEE PAGE 05-2174)

OK

REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-63)

3 CHECK HARNESS AND CONNECTOR(DLC3 – BODY GROUND)



- (a) Measure the resistance according to the value in the table below.

Standard:


Tester Connection	Specified Condition
D3-4 (CG) – Body ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK HARNESS AND CONNECTOR(ECM – DLC3)



- (a) Disconnect the ECM connector.  
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
(1MZ,3MZ) E6-20 (TC) – D3-13 (TC)	Below 1 Ω
(2AZ) E7-17 (TC) – D3-13 (TC)	Below 1 Ω

- (c) Measure the resistance according to the value(s) in the table below.


Standard:

Tester Connection	Specified Condition
D3-13 (TC) – Body ground	10 kΩ or higher

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

## 5 CHECK HARNESS AND CONNECTOR(ECM – SKID CONTROL ECU)



### 1MZ, 3MZ:

- Disconnect the skid control ECU connector S1 and ECM connector E6.
- Measure the resistance according to the value(s) in the table below.

#### Standard:

Tester Connection	Specified Condition
S1-8 (TRC+) – E6-25 (TRC+)	Below 1 $\Omega$
S1-22 (TRC-) – E6-31 (TRC-)	Below 1 $\Omega$
S1-9 (ENG+) – E6-24 (ENG+)	Below 1 $\Omega$
S1-23 (ENG-) – E6-30 (ENG-)	Below 1 $\Omega$

- Measure the resistance according to the value(s) in the table below.

#### Standard:

Tester Connection	Specified Condition
S1-8 (TRC+) – Body ground	10 k $\Omega$ or higher
S1-22 (TRC-) – Body ground	10 k $\Omega$ or higher
S1-9 (ENG+) – Body ground	10 k $\Omega$ or higher
S1-23 (ENG-) – Body ground	10 k $\Omega$ or higher

NG

**REPAIR OR REPLACE HARNESS OR CONNECTOR**

### 2AZ:

- Check CAN communication system (see page 05-2174).  
**OK:CAN communication system is normal.**

NG

**CHECK CAN COMMUNICATION SYSTEM  
(SEE PAGE 05-2174)**

OK

**REPLACE BRAKE ACTUATOR ASSY (SEE PAGE 32-63)**