


IG POWER SOURCE CIRCUIT

CIRCUIT DESCRIPTION

This is the power source for the air conditioner amplifier (contains the ECU) and servomotor, etc.

WIRING DIAGRAM



INSPECTION PROCEDURE


1 CHECK FUSE(HTR FUSE)

- (a) Remove the HTR fuse from the engine room J/B.
- (b) Check that the continuity exists of HTR fuse.

NG REPLACE FUSE

OK

2 CHECK HARNESS AND CONNECTOR(BETWEEN HEATER CONTROL HOUSING SUB-ASSY AND BATTERY)



- (a) Remove the A/C amplifier with connectors still connected.
 - (b) Turn the ignition switch to ON.
 - (c) Measure voltage between terminal IG+ of the A/C amplifier and body ground.
- Voltage: 10 - 14 V**

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE