


**VEHICLE POSITION MARK ROTATES WIHOUT CONTROL (MAP
ROTATES WITHOUT CONTROL)****WIRING DIAGRAM**

INSPECTION PROCEDURE

1 CHECK IT OPERATION AGAIN

- (a) Turn the ignition switch from OFF to ON, the check that the malfunction disappear.

STANDARD: Malfunction disappear

HINT:

Even if the works correctly, the following conditions may be seen, vehicle position mark turns, or the map turns unwillingly. (It is because by turning the IG switch to ACC or ON during turning, navigation system stores based on the angular speed). In that case, turn the IG switch from OFF to ACC or ON to return the correct function.

OK

NORMAL

NG

2 NAVIGATION CHECK MODE(VEHICLE SENSORS)

- (a) Perform vehicle signal check of navigation check mode.

- (1) Start up the diagnosis system and read of "SPD" signal in vehicle sensors mode.


STANDARD: Input signal is normal

OK

CHECK AND REPLACE NAVIGATION ECU

NG

3 INSPECT NAVIGATION ECU(SPД)




- (a) Remove the navigation ECU with connectors still connected.

- (b) Check voltage.

- (1) Shift the shift lever to neutral.
- (2) Jack up one of the front wheel.
- (3) Turn ignition switch ON.
- (4) Measure voltage between terminals SPD and GND of navigation ECU when the front wheel are turned slowly.

Voltage is generated intermittently.

9 - 14 V



OK

CHECK AND REPLACE NAVIGATION ECU

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR
