

## Service Hints

### E6 (A), E7 (B) Engine and ECT ECU (A/T), Engine ECU (M/T)

BATT–Ground : Always approx. 12 volts

IGSW–Ground : Approx. 12 volts with ignition SW at ON or ST position

EOM–Ground : Always continuity

KSW–Ground : Continuity with the key in cylinder

## ○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A17	40 (LHD)	I14	41 (LHD)	J5	A
	50 (RHD)		51 (RHD)		
E6	A	J1	41 (LHD)	J7	B
			51 (RHD)		
E7	B	J2	41 (LHD)	U1	41 (LHD)
			51 (RHD)		51 (RHD)

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	25	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1C		
2G	28	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2Q		
2R		
3A	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)
3B	34 (LHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (RHD)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace LH)

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF4	60 (LHD)	Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube)
	72 (RHD)	Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)
II1	62 (LHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH)
	74 (RHD)	Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IK2	62 (LHD)	Engine Wire and Instrument Panel Wire (Behind the Glove Box)
	74 (RHD)	

## ▽ : Ground Points

Code	See Page	Ground Points Location
ED	58 (*1)	Left Fender
	70 (*2)	
EG	58 (*1)	Left Side of Cylinder Head
	70 (*2)	
II	60 (LHD)	Cowl Side Panel LH
IN	72 (RHD)	Instrument Panel Reinforcement RH

\* 1 : LHD 2AZ–FE, 1AZ–FE

\* 2 : RHD 2AZ–FE, 1AZ–FE