


REPLACEMENT

HINT:

Installation is in the reverse order of removal.

1. **PRECAUTION** (See page 60-1)
2. **DISCONNECT BATTERY NEGATIVE TERMINAL**
3. **REMOVE FRONT SEAT ASSY LH** (See page 72-23 (POWER SEAT) OR 72-15 (MANUAL SEAT))
4. **REMOVE RECLINING POWER SEAT SWITCH KNOB (POWER SEAT)** (See page 72-23)
5. **REMOVE SLIDE & VERTICAL POWER SEAT SWITCH KNOB (POWER SEAT)** (See page 72-23)
6. **REMOVE FRONT SEAT CUSHION SHIELD INNER NO.1 LH (POWER SEAT)** (See page 72-23)
7. **REMOVE FRONT SEAT CUSHION SHIELD LH (POWER SEAT)** (See page 72-23)
8. **REMOVE RECLINING ADJUSTER RELEASE HANDLE LH (MANUAL SEAT)** (See page 72-15)
9. **REMOVE VERTICAL SEAT ADJUSTER KNOB CAP (MANUAL SEAT)** (See page 72-15)
10. **REMOVE VERTICAL SEAT ADJUSTER KNOB (MANUAL SEAT)** (See page 72-15)
11. **REMOVE FRONT SEAT CUSHION SHIELD LH (MANUAL SEAT)** (See page 72-15)



12. REMOVE SEAT SLIDE POSITION SENSOR PROTECTOR

- (a) Remove the seat slide position sensor protector from the seat position airbag sensor.

13. REMOVE SEAT POSITION AIR BAG SENSOR


- (a) Disconnect the connector from the seat position airbag sensor.
- (b) Using a torx[®] socket wrench (T30), remove the torx[®] screw and the seat position airbag sensor.

14. INSTALL SEAT POSITION AIR BAG SENSOR

- (a) Check that the ignition switch is off.
- (b) Check that the battery negative (–) terminal is disconnected.

CAUTION:

After removing the terminal, wait for at least 90 seconds before starting the operation.



- (c) Using a feeler gauge 1 mm (0.039 in.), install the seat position airbag sensor.

NOTICE:

- If the seat position airbag sensor has been dropped, or there are any cracks, dents or other defects in the case, bracket or connector, replace the seat position airbag sensor with a new one.
- When installing the seat position airbag sensor, be careful that the SRS wiring does not interfere with other parts and is not pinched between other parts.

HINT:

Be sure to maintain a clearance between the seat position airbag sensor and the seat rail is within 0.6 mm (0.023 in.) to 2 mm (0.079 in.).

- (d) Using a torx[®] socket wrench, tighten the torx[®] screw to install the seat position airbag sensor.

Torque: 8.0 N·m (82 kgf·cm, 71 in.·lbf)

- (e) Make sure that a clearance between the seat position airbag sensor and the seat rail is within 0.6 mm (0.023 in.) to 2 mm (0.079 in.).
- (f) Connect the connector to the seat position airbag sensor.
- (g) Check that there is no looseness in the installation parts of the seat position airbag sensor.

15. INSTALL FRONT SEAT ASSY LH (See page 72-23 (POWER SEAT) OR 72-15 (MANUAL SEAT))

16. INSPECT SRS WARNING LIGHT (See page 05-1456)