


BEEP SOUND SIGNAL CIRCUIT

CIRCUIT DESCRIPTION

The radio receiver assy sends a beep sound signal to the stereo component amplifier assy through this circuit.


If there is an open in the circuit, a beep sound cannot be heard from the speakers.

WIRING DIAGRAM



INSPECTION PROCEDURE



1 CHECK HARNESS AND CONNECTOR(RADIO RECEIVER ASSY - STEREO COMPONENT AMPLIFIER ASSY)



- (a) Disconnect the radio receiver assy R4 connector and stereo component amplifier assy S13 connector.
- (b) Measure the resistance according to the values in the table below.

Standard:

Tester connection	Condition	Specified condition
BEEP (R4-17) - BEEP (S13-4)	Always	Below 1 Ω
BEEP (R4-17) - Body ground	Always	10kΩ or higher



NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-1829)