

# Starting and Ignition (2AZ-FE, 1AZ-FE)

## Service Hints

### I15 Ignition SW

- 2-1 : Closed with the ignition SW at ST position
- 7-6 : Closed with the ignition SW at ON or ST position
- 7-8 : Closed with the ignition SW at ST position

### A4 Neutral Start SW (A/T)

- 9-6 : Closed with the A/T shift lever in P or N position

### S1 (A), S2 (B) Starter

- Point closed with the neutral start SW at P or N position and the ignition SW at ST position (A/T)
- Point closed with the clutch start SW on and the ignition SW at ST position (M/T)

## ○ : Parts Location

| Code | See Page | Code | See Page | Code | See Page |
|------|----------|------|----------|------|----------|
| A4   | 38 (*1)  | I2   | 39 (*1)  | J2   | 41 (LHD) |
|      | 48 (*2)  |      | 49 (*2)  | N1   | 39 (*1)  |
| E9   | 40 (LHD) | I3   | 39 (*1)  |      | 49 (*2)  |
|      | 50 (RHD) |      | 49 (*2)  | S1   | 39 (*1)  |
| E10  | 40 (LHD) | I4   | 39 (*1)  |      | 49 (*2)  |
|      | 50 (RHD) |      | 49 (*2)  | S2   | 39 (*1)  |
| I1   | 39 (*1)  | I15  | 41 (LHD) |      | 49 (*2)  |
|      | 49 (*2)  |      | 51 (RHD) |      |          |

\* 1 : LHD 2AZ-FE, 1AZ-FE

\* 2 : RHD 2AZ-FE, 1AZ-FE

## ○ : Relay Blocks

| Code | See Page | Relay Blocks (Relay Block Location)       |
|------|----------|---|
| 1    | 22       | Engine Room R/B (Engine Compartment Left) |

## ○ : Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location)                |
|------|----------|---|
| 1A   | 25       | Engine Room Main Wire and Engine Room J/B (Engine Compartment Left) |
| 1C   |          |   |
| 1E   |          |   |
| 1H   |          |   |
| 1J   |          |   |
| 1K   | 25       | Engine Wire and Engine Room J/B (Engine Compartment Left)           |
| 1L   |          |   |
| 2A   | 28       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)      |
| 2E   | 28       | Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)      |

## □ : Connector Joining Wire Harness and Wire Harness

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location)                           |
|------|----------|--|
| IF1  | 60 (LHD) | Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube) |
|      | 72 (RHD) | Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)  |
| IF3  | 72 (RHD) | Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)  |
| IF5  | 60 (LHD) | Engine Room Main Wire and Instrument Panel Wire (Right Side of Steering Column Tube) |
|      | 72 (RHD) | Engine Room Main Wire and Instrument Panel Wire (Left Side of Steering Column Tube)  |
| IK1  | 62 (LHD) | Engine Wire and Instrument Panel Wire (Behind the Glove Box)                         |
|      | 74 (RHD) |  |

**: Ground Points**

| Code | See Page | Ground Points Location     |
|------|----------|----------------------------|
| EC   | 70 (*2)  | Left Fender                |
| EG   | 58 (*1)  | Left Side of Cylinder Head |
|      | 70 (*2)  |                            |
| II   | 60 (LHD) | Cowl Side Panel LH         |

\* 1 : LHD 2AZ-FE, 1AZ-FE

\* 2 : RHD 2AZ-FE, 1AZ-FE

**: Splice Points**

| Code | See Page | Wire Harness with Splice Points | Code | See Page | Wire Harness with Splice Points |
|------|----------|---------------------------------|------|----------|---------------------------------|
| E5   | 58 (*1)  | Engine Wire                     | I3   | 74 (RHD) | Engine Room Main Wire           |
|      | 70 (*2)  |                                 | I6   | 62 (LHD) | Engine Wire                     |
| I3   | 62 (LHD) | Engine Room Main Wire           | I8   | 74 (RHD) |                                 |

\* 1 : LHD 2AZ-FE, 1AZ-FE

\* 2 : RHD 2AZ-FE, 1AZ-FE