

**WINDOW CANNOT BE OPERATED AFTER KEY-OFF****CIRCUIT DESCRIPTION**

Unless the driver's door is opened then closed within 43 seconds after the ignition switch is turned from ON to OFF, the instrument panel J/B (body ECU) supplies the power source to the master switch.

**HINT:**

If a malfunction is detected in the jam protection pulse sensor and limit switch, the operation after the ignition switch is turned OFF will be prohibited by the fail-safe function. At this time, the AUTO UP and DOWN operations will be prohibited, as well.

**INSPECTION PROCEDURE**

1	CHECK DRIVER'S SIDE POWER WINDOW FUNCTION (See page 70-1)
---	---

NG
----

GO TO PROBLEM SYMPTOMS TABLE (See page 05-2059)
--

OK
----

GO TO POWER DOOR LOCK CONTROL SYSTEM (See page 05-2072)
---