

## DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. (Proceed to the page given for that circuit.)

HINT:

The DTC detection method (See page [05-2148](#)).

DTC No. (See page)	Detection Item	Trouble Area
41 ( <a href="#">05-2080</a> )	Door ECU switch ON	<ul style="list-style-type: none"><li>• Power window master switch assey</li><li>• Unlock warning switch assey</li><li>• Front door courtesy switch assey</li><li>• Rear door courtesy switch assey</li><li>• Front door lock assey</li><li>• Headlamp dimmer switch assey</li><li>• Stop lamp switch assey</li><li>• Parking brake switch assey</li></ul>