

# ALL DOOR LOCK AND UNLOCK DO NOT OPERATE BY MASTER SWITCH OR DRIVER'S DOOR KEY


## HINT:

In the RHD vehicle, work in the same procedure as in the LHD vehicle.

## CIRCUIT DESCRIPTION

The body ECU receives a switch signal from the master switch and the driver's door key, and then drives the door lock motor.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### 1 CHECK DOOR LOCK


- (a) When the door does not operate manually, proceed to "A".  
 (b) When the door does not operate via the key, proceed to "B".

**B**

**Go to step 4**

**A**

### 2 INSPECT POWER WINDOW REGULATOR MASTER SWITCH ASSY



- (a) Disconnect the power window master switch assy.  
 (b) Check the continuity when door locking by the power window master switch assy.

**Standard:**

Terminal No.	Switch position	Specified condition
5 ⇔ 3	Lock	Continuity
-	OFF	No continuity
8 ⇔ 3	Unlock	Continuity

**NG**

**REPLACE POWER WINDOW REGULATOR MASTER SWITCH ASSY**


**OK**

### 3 CHECK WIRE HARNESS

#### Wire Harness Side


\*1 D12 \*2D13

Power Window Master Switch  
(Door Lock Control Switch)



2K

Instrument Panel J/B (Body ECU)



\*1: LHD

\*2: RHD

- (a) Disconnect the D12 or D13 power window master switch connector.  
 (b) Disconnect the 2K connector from the instrument panel J/B.  
 (c) Check the continuity between the disconnected connectors.

**Standard (LHD):**

Terminal No.	Specified condition
D12-5 ⇔ 2K-10	Continuity
D12-8 ⇔ 2K-1	Continuity

**Standard (RHD):**

Terminal No.	Specified condition
D13-5 ⇔ 2K-10	Continuity
D13-8 ⇔ 2K-1	Continuity

**OK**

**REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSY**

**NG**

**REPAIR OR REPLACE HARNESS AND CONNECTOR**

4 INSPECT FRONT DOOR W/MOTOR LOCK ASSY RH (See page 73-3)


NG REPLACE FRONT DOOR W/MOTOR LOCK ASSY RH

OK


5 CHECK WIRE HARNESS

**Wire Harness Side**


\*1 D10 \*2 D11 Door Lock



2H  
Instrument Panel J/B



B7  
Instrument Panel J/B (Body ECU)



\*1: LHD  
\*2: RHD

B52057

- (a) Disconnect the D10 or D11 door lock (driver side) connector.
- (b) Disconnect the B7 and 2H connectors from the instrument panel J/B.
- (c) Check the continuity between the disconnected connector terminals.

Standard (LHD) (w/o double door lock):

Terminal No.	Specified condition
2H-11 ↔ D10-4	Continuity
B7-4 ↔ D10-1	Continuity

Standard (LHD) (w/ double door lock):

Terminal No.	Specified condition
2H-11 ↔ D10-2	Continuity
B7-4 ↔ D10-1	Continuity

Standard (RHD) (w/o double door lock):

Terminal No.	Specified condition
2H-11 ↔ D11-4	Continuity
B7-4 ↔ D11-1	Continuity

Standard (RHD) (w/ double door lock):

Terminal No.	Specified condition
2H-11 ↔ D11-2	Continuity
B7-4 ↔ D11-1	Continuity

NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSY