


OVERHAUL

HINT:

COMPONENTS: [See page 55-67](#)

1. DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM [See page 55-8](#)

SST 07110-58060 (07117-58080, 07117-58090, 07117-78050, 07117-88060, 07117-88070, 07117-88080)



2. REMOVE COOLER REFRIGERANT DISCHARGE HOSE NO.1

- Remove the bolt and disconnect the cooler refrigerant discharge hose No. 1 from the cooler condenser assy.
- Remove the O-ring from the cooler refrigerant discharge hose No. 1.

NOTICE:

Seal the opening of the disconnected parts using vinyl tape to prevent moisture and foreign matter from entering.

3. DISCONNECT COOLER REFRIGERANT LIQUID PIPE A (LHD STEERING POSITION TYPE)

- Remove the bolt and disconnect the cooler refrigerant liquid pipe A from the cooler condenser assy.
- Remove the O-ring from the cooler refrigerant liquid pipe A.

NOTICE:

Seal the opening of the disconnected parts using vinyl tape to prevent moisture and foreign matter from entering.

4. DISCONNECT COOLER REFRIGERANT LIQUID PIPE A (RHD STEERING POSITION TYPE)

- Remove the bolt and disconnect the cooler refrigerant liquid pipe A from the cooler condenser assy.
- Remove the O-ring from the cooler refrigerant liquid pipe A.

NOTICE:

Seal the opening of the disconnected parts using vinyl tape to prevent moisture and foreign matter from entering.

5. REMOVE AIR CLEANER INLET ASSY

1MZ-FE: [See page 16-36](#)

1AZ-FE: [See page 16-11](#)



2AZ-FE: [See page 16-23](#)


6. REMOVE RADIATOR SUPPORT UPPER

1MZ-FE: [See page 16-36](#)

1AZ-FE: [See page 16-11](#)


2AZ-FE: [See page 16-23](#)






7. REMOVE COOLER CONDENSER ASSY

- (a) Remove the 2 nuts and cooler condenser assy.




8. REMOVE COOLER DRYER

- (a) Using hexagon wrench 10 mm (0.39 in.), remove the cap and filter from the modulator.




- (b) Remove the 2 O-rings from the cap.



- (c) Using a needle nose pliers, remove the cooler dryer.


9. INSTALL COOLER DRYER

- (a) Using a needle nose pliers, install the cooler dryer.




- (b) Install 2 new O-rings to the cap.
 (c) Sufficiently apply compressor oil to the fit surfaces of the O-ring and the cap.

Compressor oil: ND-OIL 8 or equivalent



- (d) Using hexagon wrench 10 mm (0.39 in.), install the cap to the cooler/condenser assy.

Torque: 12 N·m (125 kgf·cm, 9 ft·lbf)



10. INSTALL COOLER/CONDENSER ASSY

- (a) Install the cooler/condenser assy with the 2 nuts.

Torque: 9.8 N·m (100 kgf·cm, 85 in·lbf)

11. INSTALL RADIATOR SUPPORT UPPER

1MZ-FE: (See page 16-36)

1AZ-FE: (See page 16-11)


2AZ-FE: (See page 16-23)

12. INSTALL COOLER REFRIGERANT LIQUID PIPE A (LHD STEERING POSITION TYPE)

- (a) Remove the attached vinyl tape from the tube and connecting part of the cooler condenser assy.
- (b) Sufficiently apply compressor oil to the new O-ring and tube joint.

Compressor oil: ND-OIL 8 or equivalent

- (c) Install a O-ring to the cooler refrigerant liquid pipe A.



- (d) Connect the cooler refrigerant liquid pipe A to the cooler condenser assy with the bolt.

Torque: 5.4 N·m (55 kgf·cm, 47 in·lbf)


13. INSTALL COOLER REFRIGERANT LIQUID PIPE A (RHD STEERING POSITION TYPE)

- (a) Remove the attached vinyl tape from the tube and connecting part of the cooler condenser assy.

- (b) Sufficiently apply compressor oil to the new O-ring and tube joint.

Compressor oil: ND-OIL 8 or equivalent

- (c) Install a O-ring to the cooler refrigerant liquid pipe A.



- (d) Connect the cooler refrigerant liquid pipe A to the cooler condenser assy with the bolt.

Torque: 5.4 N·m (55 kgf·cm, 47 in.·lb)

14. INSTALL COOLER REFRIGERANT DISCHARGE HOSE NO.1

- (a) Remove the attached vinyl tape from the tube and connecting part of the cooler condenser assy.


- (b) Sufficiently apply compressor oil to the new O-ring and tube joint.

Compressor oil: ND-OIL 8 or equivalent

- (c) Install a O-ring to the cooler refrigerant discharge hose No. 1.

- (d) Connect the cooler refrigerant discharge hose No. 1 to the cooler condenser assy with the bolt.

Torque: 5.4 N·m (55 kgf·cm, 47 in.·lb)



15. CHARGE REFRIGERANT (See page 55-8)

SST 07110-58060 (07117-58060, 07117-58070, 07117-58080, 07117-58090, 07117-78050, 07117-88060, 07117-88070, 07117-88080)

Specified amount:

LHD: 550 ± 50 g (19.37 ± 1.76 oz.)

RHD: 580 ± 50 g (21.86 ± 1.76 oz.)

16. WARM UP ENGINE

17. INSPECT LEAKAGE OF REFRIGERANT (See page 55-8)