

FRONT SEAT ASSEMBLY LH (MANUAL SEAT TYPE)

COMPONENTS

72077-01

In RHD vehicle, look in the same location as in the LHD vehicle.

Front Seat Headrest Assy

Front Seat Headrest Support

Front Seat Back Spring Assy

Front Seat Back Pad

w/ Seat Heater:

Front Seat Back Heater Assy LH

Separate Type Front Seat Back Cover

◆ Hog Ring

Separate Type Front
Seat Cushion Cover

◆ Hog Ring

Separate Type Front
Seat Cushion Pad

w/ Seat Heater:

Front Seat Cushion Heater Assy LH

Only for Driver's Seat:

Lumber Support Adjuster Assy

Snap Ring

Only for Driver's Seat:

Reclining Adjuster Knob

42 (428, 30)

Front Seat Inner Belt Assy

Front Seat Cushion Shield Inner LH

Reclining Adjuster Cover LH

Reclining Adjuster Release Handle

Reclining Adjuster
Inside Cover RH

Reclining Adjuster Inside Cover LH

Front Seat Track Cover LH Rear Inner

Front Seat Track Cover
LH Rear Outer

Front Seat Cushion Spring Assy

36.8 (377, 27)

43.1 (440, 32)

36.8 (377, 27)

Snap Ring

Reclining Vertical Adjuster Knob

N·m (kgf·cm, ft·lbf) : Specified torque ◆ Non-reusable part

B57291