

# STARTING & CHARGING

## SERVICE DATA

030F8-03

### 1AZ-FE

Starter assy Specified current		90 A or less at 11.5 V
Battery Voltage	Standard	12.5 - 12.9 V at 20°C (68°F)

### 2AZ-FE

Starter assy Specified current		90 A or less at 11.5 V
Battery Voltage	Standard	12.5 - 12.9 V at 20°C (68°F)

### 1MZ-FE

Starter assy Specified current		90 A or less at 11.5 V
Battery Voltage	Standard	12.5 - 12.9 V at 20°C (68°F)