


TERMINALS OF ECU


1. WINDSHIELD WIPER RELAY ASSY



E57895

Symbols (Terminals No.)	Wiring Color	Condition	Specified condition
IG ⇔ E (1 - 13)	L ⇔ WB	IG SW ON	9 - 16 V
+SM ⇔ E (2 - 13)	G -B ⇔ WB	Wiper stop position → Except stop position	Below 1 V → 10 - 14 V
+1 ⇔ E (11 - 13)	B-R ⇔ WB	Wiper SW except LO → LO	Below 1 V → 10 - 14 V
+2 ⇔ E (12 - 13)	L-O ⇔ WB	Wiper SW except HI → HI	Below 1 V → 10 - 14 V
SIG ⇔ E (6 - 13)	P-B ⇔ WB	IG SW ON	8 V
SPD ⇔ E (16 - 13)	LG ⇔ WB	Wiper SW except AUTO	5 V
PA1 ⇔ E (17 - 13)	V ⇔ WB	Wiper is stopped	5.4 - 8 V
VR1 ⇔ VR2 (8-18)	GR-R ⇔ WB	Sensitivity volume HI → LO	0 kΩ → 2.7 kΩ
C1 ⇔ CO (9 - 19)	O ⇔ WB	Wiper SW AUTO	Continuity
+SSW ⇔ +25 (10 - 20)	L-Y ⇔ WB	Wiper SW OFF or AUTO	Continuity
W ⇔ E (5 - 13)	P ⇔ WB	Washer SW OFF → ON	No continuity → Continuity
E ⇔ Body ground (13 - Body ground)	W-B ⇔ WB	Constant	Continuity

2. RAIN SENSOR



E57896

Symbols (Terminals No.)	Wiring Color	Condition	STD Voltage (V)
SIG ⇔ ES (1 - 4)	P-B ⇔ W-B	IG SW ON	8 V
AUTO ⇔ ES (2 - 4)	V ⇔ W-B	Wiper is stopped	6.8 V
WIP ⇔ ES (3 - 4)	LG ⇔ W-B	Wiper SW except AUTO	3.5 - 5 V
ES ⇔ Body ground (4 - Body ground)	W-B ⇔ -	Continuity	Continuity