

<b>DTC</b>	<b>P0607/54</b>	<b>CONTROL MODULE PERFORMANCE</b>
------------	-----------------	-----------------------------------

## CIRCUIT DESCRIPTION

This circuit indicates failure of the stop lamp switch signal and the cruise control signal inside ECM.

DTC No.	Detection Item	Trouble Area
P0607/54	<ul style="list-style-type: none"><li>• Cruise control switch input signal abnormal.</li><li>• Stop lamp switch input signal abnormal.</li></ul>	<ul style="list-style-type: none"><li>• ECM</li></ul>

## INSPECTION PROCEDURE

<b>1</b>	<b>READ VALUE OF HAND-HELD TESTER</b>
----------	---------------------------------------

- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the item "CCS READY" in the DATA LIST and read its value displayed on the hand-held tester.

**OK:**

**ON" ⇔ "OFF: Change ON/OFF each time Main SW is pressed on.**

**NG** ➤

**CHECK AND REPLACE ECM**

**OK**

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**  
(See page [05-2218](#))