


## INSPECTION

### HINT:

- On the RH side, use in the same procedure as on the LH side.




### 1. INSPECT SEAT HEATER SWITCH

- (a) Inspect the seat heater switch (driver's side) continuity.

#### Standard:

Terminal No.	Condition	Specified condition
4 ↔ 6	OFF	Continuity
3 ↔ 4 ↔ 6	ON	Continuity
1 ↔ 2	Illumination	Continuity (always)

If the continuity is not as specified, replace the seat heater switch.




- (b) Inspect the seat heater switch (passenger's side) continuity.

#### Standard:

Terminal No.	Condition	Specified condition
4 ↔ 6	OFF	Continuity
3 ↔ 4 ↔ 6	ON	Continuity
1 ↔ 2	Illumination	Continuity (always)

If the continuity is not as specified, replace the seat heater switch.




### 2. INSPECT FRONT SEAT CUSHION HEATER ASSY LH

- (a) Inspect the seat cushion heater assembly LH continuity.

#### Standard:

Terminal No.	Condition	Specified condition
1 ↔ 2	Constant	Continuity

If the continuity is not as specified, replace the seat cushion heater assembly.




### 3. INSPECT FRONT SEAT BACK HEATER ASSY LH

- (a) Inspect the seat back heater assembly LH continuity.

#### Standard:

Terminal No.	Condition	Specified condition
1 ↔ 2	Constant	Continuity

If the continuity is not as specified, replace the seat back heater assembly.



- (b) Inspect the seat cushion thermostat continuity.
- (1) Disconnect the seat back heater from the seat cushion heater LH.
  - (2) Heat up the thermostat LH with a heat light.
  - (3) Inspect the seat cushion heater continuity between the terminals.

**Standard:**

Terminal No.	Condition	Specified condition
1 ↔ 2	Seat heater temp. below 25 – 35°C (77 – 95°F)	Continuity
	Seat heater temp. 25 – 35°C (77 – 95°F)	No continuity

If the continuity is not as specified, replace the seat heater cushion heater assembly.

4. **INSPECT FRONT SEAT CUSHION HEATER ASSY RH**
5. **INSPECT FRONT SEAT BACK HEATER ASSY RH**